MVC-FD81

SERVICE MANUAL

Self Diagnosis Supported model

Ver 1.0 1998.09

US Model
Canadian Model
AEP Model
UK Model
E Model
Australian Model
Hong Kong Model
Tourist Model
Chinese Model

Digital
Mavica

SPECIFICATIONS

System

Image device	1/3-inch CCD
Lens	3x f = 5.2 – 15.6 mm (37 – 111 mm, when converted to the equivalent of a 35 mm still camera) F2.0 – 2.1
Exposure control	Automatic exposure
White balance	Automatic
Data compression	Movie : MPEG-1 Standard format Still : JPEG Audio with still image : MPEG audio (mono)
Memory	Floppy disk: 3.5 inch 2HD MS-DOS format (1.44 MB)
Flash	Recording distance limitations: 1 5/8 – 8 1/3ft. (0.5 – 2.5 m)

LCD screen

Screen size	2.5 inch
LCD panel	TFT
Total dot number	84260 dots

General

Application	Sony battery pack NP-F330/F530/F550
Power requirements	7.2 V (battery pack)
Power consumption (During shooting)	3.5 W
Operation temperature	32°F to +104°F (0°C to +40°C)
Storage temperature	–4°F to 140°F (–20°C to 60°C)
Dimensions	Approx. 5 5/8 × 4 1/8 × 2 1/2 in. (140.5 × 104.5 × 61 mm) (w/h/d)
Mass	Approx. 1 lb. 7 oz. (650 g) (including battery pack NP-F330, lithium battery CR2025, floppy disk, shoulder strap and lens cap)
Microphone	Electret condenser microphone
Speaker	Dynamic Speaker
Supplied accessories	See page 1-1.

Design and specifications are subject to change without notice.

DIGITAL STILL CAMERA

MICROFILM

SONY®

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK ⚠ OR DOTTED LINE WITH MARK ⚠ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFÉS PAR UNE MARQUE ⚠ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer.

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, through functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the B+ voltage to see it is at the values specified.
6. Flexible Circuit Board Repairing
   - Keep the temperature of the soldering iron around 270˚C during repairing.
   - Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
   - Be careful not to apply force on the conductor when soldering or unsoldering.

TABLE OF CONTENTS

SERVICE NOTE ····· 5

1. GENERAL

Before using your camera 1-1
Parts identification 1-1
Basic operations
Preparation 1-2
1: Charging the battery pack 1-2
2: Installing the battery pack 1-2
3: Setting the date and time 1-2
Recording and playing back images 1-3
1: Recording still images 1-3
2: Recording moving images 1-3
3: Playing back still images 1-4
4: Playing back moving images 1-4
Battery life/No. of images that can be recorded/ played back 1-5
Viewing images using a personal computer 1-5
Advanced operations
Changing the mode settings 1-5
Using various functions for recording 1-8
Focusing manually 1-8
Enjoying Picture Effect 1-8
Using the PROGRAM AE function 1-8
Additional information
Charging the lithium battery in the camera 1-8
Precautions 1-9
Troubleshooting 1-9
Self-diagnosis display 1-10
Warning messages 1-10

2. DISASSEMBLY

2-1. Cabinet (Front) Assembly, Cabinet (Rear) Assembly 2-1
2-2. FC-67 Board, DD-119 Board, Floppy Disk Drive 2-2
2-3. PK-44 Board, LCD Panel 2-2
2-4. RL-51 Board, FLASH Unit 2-3
2-5. CD-206 Board, Lens Device 2-3
2-6. Service Position (Routing and location of harnesses) 2-4
2-7. Service Position (For voltage measurement) 2-5
2-8. Circuit Boards Location 2-6

3. BLOCK DIAGRAMS

3-1. Overall Block Diagram 3-1
3-2. Camera/FDD Interface Block Diagram 3-5
3-3. Mode Control Block Diagram 3-9
3-4. LCD Block Diagram 3-11
3-5. Power Block Diagram 3-13

4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. Frame Schematic Diagram 4-1
4-2. Printed Wiring Boards and Schematic Diagrams 4-5
• CD-206 (CCD Imager)
Printed Wiring Board 4-6
• CD-206 (CCD Imager)
Schematic Diagram 4-7
• FC-67 (Camera Y/C Process, DRAM Control, Lens Motor Drive, D/A Converter, Audio A/D.D/A Converter, FD/System Control, HI Control)
Printed Wiring Board 4-9
• FC-67 (Camera Y/C Process)(1/7)
Schematic Diagram 4-14
• FC-67 (DRAM Control)(2/7)
Schematic Diagram 4-17
• FC-67 (Lens Motor Drive)(3/7)
Schematic Diagram 4-23
• FC-67 (D/A Converter)(4/7)
Schematic Diagram 4-25
• FC-67 (Audio D/A.A/D Converter)(5/7)
Schematic Diagram 4-29
• FC-67 (FD/System Control)(6/7)
Schematic Diagram 4-31
• FC-67 (HI Control)(7/7)
Schematic Diagram 4-36
• PK-44 (REC/PB AMP)(1/5)
Schematic Diagram 4-39
• PK-44 (LCD Drive)(2/5)
Schematic Diagram 4-43
• PK-44 (Timing Generator)(3/5)
Schematic Diagram 4-45
• PK-44 (Back-Light, Mode Switch)(4/5)(5/5)
Schematic Diagram 4-48
• PK-44 (REC/PB AMP, LCD Drive, Timing Generator, Back-Light, Mode Switch)
Printed Wiring Board 4-51
• DD-119 (DC/DC Converter)
Schematic Diagram 4-55
• DD-119 (DC/DC Converter)
Printed Wiring Board 4-59
• RL-51 (MIC AMP)
Printed Wiring Board and Schematic Diagram 4-62

5. ADJUSTMENTS

5-1. Camera Section Adjustment 5-1
1-1. Preparations before Adjustment (Camera Section) 5-1
1-1-1. List of Service Tools 5-1
1-1-2. Preparations 5-2
1-1-3. Discharging of the flashlight power supply 5-2
1-1-4. Precaution 5-4
1. Setting the Switch 5-4
2. Order of Adjustments 5-4
3. Subjects 5-4
1-2. Initialization of F, E Page Data 5-5
1. Initializing the F, E Page Data 5-5
2. Modification of F, E Page Data 5-5
3. F Page Table 5-5
4. E Page Table 5-7
1-3. Camera System Adjustments 5-10
1. Picture Frame Setting 5-10
2. HALL Adjustment 5-11
3. Flange Back Adjustment 5-11
4. Flange Back Check 5-12
5. Light Level Adjustment 5-12
6. Auto White Balance Standard Data Input 5-13
7. Auto White Balance Adjustment 5-13
8. Color Reproduction Adjustment 5-14
9. White Balance Check 5-15
10. Strobe Light Level Adjustment 5-15
11. Strobe White Balance Adjustment 5-16
12. Strobe Light Level and White Balance Check 5-16
13. CCD Defect Compensation 5-17
14. CCD Defect Compensation Check 5-17
1-4. LCD System Adjustment 5-18
1. LCD Initial Data Input 5-18
2. VCO Adjustment (PK-44 board) 5-19
3. D range Adjustment (PK-44 board) 5-19
4. Bright Adjustment (PK-44 board) 5-20
5. Contrast Adjustment (PK-44 board) 5-20
6. Color Adjustment (PK-44 board) 5-21
7. V-COM Level Adjustment (PK-44 board) 5-21
8. V-COM Adjustment (PK-44 board) 5-22
9. White Balance Adjustment (PK-44 board) 5-22

1-5. System Control System Adjustment 5-23
1. Battery End Adjustment (FC-67 board) 5-23
2. Alignment Check (FDD Unit) 5-24
5-2. Service Mode 5-25
2-1. Adjustment Remote Commander 5-25
1. Using the Adjustment Remote Commander 5-25
2. Precautions upon using the adjustment remote commander 5-25
2-2. Data Process 5-26
2-3. Service Mode 5-27
1. Setting the Test Mode 5-27
2. Bit value discrimination 5-27
3. Switch Check (1) 5-27
4. Switch Check (2) 5-28
5. Self Diagnosis Log Check 5-28

6. REPAIR PARTS LIST

6-1. Exploded Views 6-1
6-1-1. Cabinet (Front) Section 6-1
6-1-2. Cabinet (Rear) Section 6-2
6-1-3. Lens Block Section 6-3
6-2. Electrical Parts List 6-4

* The color reproduction frame is shown on page 149.

[Discharging of the FLASH unit's charging capacitor]

The charging capacitor of the FLASH unit is charged up to the maximum 300 V potential.
There is a danger of electric shock by this high voltage when the battery is handled by hand. The electric shock is caused by the charged voltage which is kept without discharging when the main power of the MVC-FD81 is simply turned off. Therefore, the remaining voltage must be discharged as described below.

Preparing the Short Jig

To preparing the short jig. a small clip is attached to each end of a resistor of 1kΩ /1W (1-215-869-11)
Wrap insulating tape fully around the leads of the resistor to prevent electrical shock.



Discharging the Capacitor

Short circuits between the positive and the negative terminals of charged capacitor with the short jig about 10 seconds.



[How to connect the extension cable]

1. Connection between the FDD unit and PK-44 board.

1) Connection of the extension cable (J-6082-427-A)



Fig.1

2) Connection between the PK-44 board and extension cable



Fig.2

3) Connection between the FDD unit and extension cable



Fig.3

Note : The floppy disk drive and PK-44 board could be destroyed unless the flexible board is connected normally to the connector. (See Fig. 4.)



Fig.4

2. Connection between the DD-119 board and FC-67 board



Fig.5

[Description on Self-diagnosis Display]

Self-diagnosis display

The camera has a self-diagnosis display. This function displays the camera condition with five-digits (a combination of a letter and figures) on the LCD screen. If this occurs check the following code chart. The five-digit display informs you of the camera current condition. The last two digits (indicated by □□) will differ depending on the state of the camera.



Self-diagnosis display

- C: □□: □□
  The contents which can be handled by customer, are displayed.
- E: □□: □□
  The contents which can be handled by engineer, are displayed.

Note : The "Self-diagnosis" data is backed up by the coin lithium battery.The data will be lost and initialized when the coin lithium battery is removed.

Display Code	Countermeasure	Cause	Caution Display During Error
C:32:01	Change the disk and turn off the main power then back on.	Defective floppy disk.	DRIVE ERROR
C:13:01	Replace the floppy disk. Format the floppy disk with the MVC-FD81.	• The type of floppy disk that cannot be used by this machine, is inserted. (Such as 2DD) • Data is damaged. • Unformatted disk is inserted.	DISK ERROR
E:91:01	Checking of flash unit or replacement of flash unit	Abnormality when flash is being charged.	Flash LED Flash display Flashing at 3.2 Hz
E:61:00	Checking of lens drive circuit	When failed in the focus initialization.	—
E61:10			

Be sure to read before using your camera

Trial recording

Before you record one-time events, you may want to make a trial recording to make sure that the camera is working correctly.

No compensation for contents of the recording

Contents of the recording cannot be compensated for if recording or playback cannot be made due to a malfunction of the camera, floppy disk, etc.

Precaution on copyright

Floppy disks, television programs, films, video tapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the provisions of the copyright laws.

- IBM PC/AT is a registered trademark of International Business Machines Corporation of the U.S.A.
- MS-DOS and Windows are registered trademarks licensed to Microsoft Corporation, registered in the U.S.A. and other countries.
- Netscape Navigator is a trademark of Netscape Communications Corporation.
- Macintosh is a trademark licensed to Apple Computer, Inc., registered in the U.S.A. and other countries.
- All other product names mentioned herein may be the trademarks or registered trademarks of their respective companies. Furthermore, "TM" and "®" are not mentioned in each case in this manual.

Before using your camera

This digital still camera uses a floppy disk as a medium for recording images.
Use the following floppy disk type:

- Size: 3.5 inch
- Type: 2HD
- Capacity: 1.44 MB
- Format: MS-DOS format (512 bytes × 18 sectors)

When using 3.5 inch, 2HD floppy disk other than described above, format it using the camera or personal computer.

Do not shake or strike the unit

Malfunctions, inability to record images as well as inability to use floppy disks or image and memory data breakdown, damage or loss may occur.

Do not get the unit wet

When taking pictures outdoors in the rain or under similar conditions, be careful not to get the unit wet.
If moisture condensation occurs, refer to page 39 and follow instructions on how to remove it before using.

Back up recommendations

To avoid the potential risk of data loss always copy (back up) data to disk.

Supplied accessories

Digital still camera (1)
Power cord (1 set)
Shoulder strap (1)
Battery charger (1)
NP-F330 battery pack (1)
Lens cap (1)
String for lens cap (1)

Parts identification

See pages in ( ) for more details.


Microphone
Do not touch when recording.
Shutter button (16, 17)
Photocell window for flash
Do not block when recording.
Slot for AC power adaptor code
Flash emitter (10)
Self-timer lamp
The lamp keeps on blinking until recording starts after the shutter button is depressed.
Lens
Focus ring (34)
Lens cap
FOCUS AUTO/ MANU switch (34)
Tripod receptacle
Make sure that the length of the tripod screw is less than 7/32 inch (6.5 mm).

To insert the floppy disk

Insert the floppy disk until it clicks.



Before inserting, check that the write protect tab set to the recording position.



To remove the floppy disk

While pressing PUSH, slide DISK EJECT in the direction of the arrow.


LCD BACK LIGHT switch
Normally select ON.
Set to OFF to save the battery.
BRIGHT +/– button
Press to adjust the brightness of the LCD screen.
PLAY/STILL/MOVIE switch (16, 17, 19)
Lithium battery compartment (37)
PICTURE EFFECT button (35)
PROGRAM AE button (36)
DISPLAY button
Press to display or turn off the indicators on the LCD screen.
The indicators do not go off in the following modes:
Program AE, Picture effect, Manual focus, Zoom, AE Lock, Self-timer, Flash and Adjusting the exposure.
Hooks for strap
Attaching the shoulder strap
LCD screen
POWER switch
Slide down to turn on/off the power.
ACCESS lamp (16, 19)
DISK EJECT lever (8)
Battery cover/ OPEN (BATT) button (12)
PUSH button (8)
Control button


Control button
Upper side
Left side
Right side
Lower side
Press to execute.
Function of the control button
You can execute the functions by pressing the upper, lower, left or right side of the control button. When an item is selected in the menu, the color of the item changes from blue to yellow. To enter your selection, press the center of the control button.

Zoom lever
"T" side: for telephoto (subject appears closer)
"W" side: for wide-angle (subject appears farther away)
Move the zoom lever to the "W" side until the focus is sharp.
You can shoot a subject that is at least about 5/6 feet (about 25 cm) away from the lens surface in the telephoto position, or about 1/2 inch (about 1 cm) away in the wide-angle position.


Photocell window for LCD screen
The LCD screen becomes brighter when exposed to sunlight.
VOLUME +/– button
Press to adjust the volume of the speaker.
FLASH/CHARGE lamp
FLASH button
AUTO is set at the factory. Each time you press the button, the flash mode changes as follows:
AUTO (no indication) → forced-flash → no flash → AUTO
In AUTO mode, the flash goes off automatically according to the brightness of the surroundings.
The subject must be 1 5/8 feet to 8 1/3 feet (0.5 m to 2.5 m) away.
When you record using the flash and conversion lens (not supplied), an eclipse may occur.
Floppy disk slot
POWER lamp (16, 19)
Speaker
Self-timer
Select "⏲" with the control button, then press it.
About 10 seconds after you press the shutter button, the subject is recorded.
Exposure
Select "+EV" or "–EV" on the LCD screen with the control button, then press it to select the desired value.
+EV: To raise the exposure value (brighten the picture)
–EV: To lower the exposure value (darken the picture)
Adjustable in a range of –1.5 EV to +1.5 EV in steps of 0.5 EV.

Preparation

1 Charging the battery pack

To charge the battery pack, use the battery charger. For details, refer to the instruction manual of the battery charger.


❶ Connect the power cord to a wall outlet.
❷ Insert the battery pack in the direction of the ▼ mark. Slide it down until it clicks.
CHARGE lamp (orange)
The CHARGE lamp (orange) lights up. Charging begins.
Battery charger

To remove the battery pack

Slide up the battery pack.

Charging time

Battery	Full charge*	Normal charge**
NP-F330	210 min.	150 min.
NP-F530	225 min.	165 min.
NP-F550	240 min.	180 min.

Approximate minutes to charge a discharged battery pack using the battery charger BC-V615. (Lower temperatures require a longer charging time.)
* Charging for about one hour after the CHARGE lamp goes out.
** Charging just until the CHARGE lamp goes out.

⇨ Preparation

2 Installing the battery pack

❶ 

Open the battery cover.
While sliding OPEN (BATT) in the direction of the arrow.

❷ 

Install the battery pack.
Insert the battery pack with the ▼ mark facing toward the battery compartment.

❸ 

Close the cover.
Press the cover until it clicks.

To remove the battery pack

Open the battery cover. While sliding the battery release lever rightward, remove the battery pack.
Be careful not to drop the battery pack when removing.



Remaining battery time indication

This camera shows on the LCD panel how many minutes you can still keep on recording or playing back images*. Note, however, that the time might not be displayed correctly under some use conditions or in some environments.
* The time displayed during recording or during playback refers to the time for which the battery lasts if you simply keep the camera on or if you simply keep it displaying images without performing any operation.

Auto power-off function

During recording if you leave the camera inactive for about 3 minutes while the power is on, the camera turns off automatically to prevent wearing down the battery.

About the power source

This camera can be powered from the following two power sources:
• InfoLITHIUM battery* NP-F330 (supplied)/F530 (not supplied)/F550 (not supplied)
• AC power adapter AC-V700 (not supplied)
When you use the camera for a long time, we recommend you to power the camera from a wall outlet with the AC power adaptor.

*** "InfoLITHIUM" battery pack**
The "InfoLITHIUM" is a lithium ion battery pack which can exchange data with compatible equipment about its battery consumption.
"InfoLITHIUM" is a trademark of Sony Corporation.

3 Setting the date and time

When you use the camera first, set the date and time.
The date and time are necessary for MS-DOS format recording. If they are not set, incorrect date and time are recorded, and CLOCK SET screen in step ❸ appears whenever you turn on the camera in STILL/MOVIE mode.

❶ Slide POWER down to turn on the power.

❷ Select "CLOCK SET" in MENU with the control button, then press it.



⇨Preparation

❸ Select the desired display of the date with the control button, then press it.

Y/M/D (year/month/day)
M/D/Y (month/day/year)
D/M/Y (day/month/year)



❹ Select the date and time with the control button, then press it.

The item to be changed is indicated with ▲/▼. Select number by pressing the upper side or lower side of the control button, then press it to enter the number.
After entering the number, ▲/▼ moves to the next item.
When "D/M/Y" is selected, set the time on a 24-hour cycle.



❺ Select "ENTER" with the control button, then press it at the desired moment to begin clock movement.



To cancel setting the date and time

Select "CANCEL" with the control button, then press it.

Note

If the "⚠" indicator appears on the LCD screen, replace the lithium battery according to the procedures on page 37.

Recording and playing back images

1 Recording still images

To record the images, slide POWER down to turn on the power (The POWER lamp lights up) and insert the floppy disk until it clicks.



❶ Set PLAY/STILL/MOVIE to STILL.

❷ Press the shutter button halfway down.
The AE lock indicator ◉ (green) flashes. When AE (auto exposure), AWB (auto white balance) and AF (auto focus) are frozen, the AE lock indicator stops flashing.



❸ Press the shutter button fully down.
The image is recorded on the disk.

The number of images you can record on a floppy disk
About 10 – 16 images with all default settings. (p. 27)

Note

When the image is recorded on the disk, the ACCESS lamp flashes.
When the ACCESS lamp is flashing, never shake or strike the unit. Also, do not turn the power off or remove the battery pack or floppy disk. Otherwise, an image data breakdown may occur and the floppy disk may become unusable.

2 Recording moving images

❶ Set PLAY/STILL/MOVIE to MOVIE.

❷ Press the shutter button fully down momentarily.
The image and sound are recorded for 5 seconds.
Hold the shutter button fully down.
The image and sound are recorded until you release it.
Maximum 60 seconds when recording 160 × 112 size 🎞160
15 seconds when recording 320 × 240 size 🎞320

Moving images will be softer than still images.

Functions you can use for image recording

Adjusting the brightness of the LCD screen (p. 9)
Flash (p. 10)*
Zoom (p. 10)
Self-timer (p. 10)
Adjusting the exposure (p. 10)
Focusing manually (p. 34)
Picture effect (p. 35)
PROGRAM AE function (p. 36)
Selecting the recording mode – REC MODE (p. 26)*
Selecting the image quality – QUALITY (p. 28)*
Selecting the flash level – FLASH LEVEL (p. 28)*
Selecting the file numbering mode – FILE NUMBER (p. 29)
Selecting the image size – IMAGE SIZE (p. 28, 29)

* You cannot use these functions for MOVIE mode.

⇨Recording and playing back images

The indicators during recording

The indicators on the LCD screen are not recorded.



* Only displayed during operation.

3 Playing back still images

To watch the recorded images on the LCD screen, slide POWER down to turn on the power (The POWER lamp lights up) and insert the floppy disk until clicks.



❶ Set PLAY/STILL/MOVIE to PLAY.
The ACCESS lamp flashes and the last recorded image appears on the LCD screen.

❷ Select the recorded image with the control button.
Select the button on the LCD screen with the control button, then press it.

- [⏮]: To display the preceding recorded image.
- [⏭]: To display the next image.
- [INDEX]: To display 6 recorded images at a time (INDEX screen).

4 Playing back moving images

❶ Set PLAY/STILL/MOVIE to PLAY.
The ACCESS lamp flashes and the last recorded image appears on the LCD screen.
The image recorded in MOVIE mode is displayed one-size smaller than the other normal-sized images.

❷ Select the playback start button on the LCD screen with the control button, then press it.
The moving image and sound start.

⇨Recording and playing back images

The indicators during playback

During playback still images (STILL)



During playback moving images (MOVIE)/Still images with sounds (VOICE)



In INDEX screen mode

- [⬅]: To display the preceding 6 images.
- [➡]: To display the following 6 images.



- [🎞]: Moving image file
- [♪]: Still image with sound file

- To return to the normal playback screen (Single screen), select an image with the control button, then press it.
- The number displayed at the upper right side of the image shows the recording order on the disk. It is different from the file name (p. 27).

Functions you can use for playback of recorded images

Adjusting the volume of the speaker (p. 10)
Adjusting the brightness of the LCD screen (p. 9)
Protecting images – PROTECT (p. 30)
Copying recorded images to another floppy disk – COPY (p. 31)
Deleting images – DELETE (p. 32)

Note

The images recorded by this camera may not be played back correctly by MVC-FD5/FD7/FD51/FD71/FDR1/FDR3.

⇨Recording and playing back images

Battery life/No. of images that can be recorded/played back

STILL mode

Battery		Battery life (min.)	No. of images (record/playback)
NP-F330	Continuous recording*	55 (50)	650 (550)
(Supplied)	Continuous playing**	100 (90)	1500 (1350)
NP-F530	Continuous recording*	90 (80)	1100 (950)
	Continuous playing**	160 (140)	2400 (2100)
NP-F550	Continuous recording*	120 (110)	1500 (1350)
	Continuous playing**	210 (190)	3100 (2800)

Approximate battery life and no. of images that can be recorded/played back at a temperature of 77°F (25°C), 640 × 480 image size, in NORMAL recording and STANDARD quality mode. Numbers in parentheses indicate the time when using a normally charged battery. The battery life and no. of images are the same as when using the flash. If you record 1240 × 768 size images, the no. of images that can be recorded is reduced from the above figures by about 10%.

* Recording at about 5 second intervals
** Playing back single image at about 4 second intervals

MOVIE mode

Battery		Battery life (min.)	No. of images (record)
NP-F330 (Supplied)	Continuous recording	60 (55)	40 (35)
NP-F530	Continuous recording	100 (90)	65 (55)
NP-F550	Continuous recording	140 (125)	90 (80)

Approximate minutes that can be recorded at a temperature of 77°F (25°C) and 160 × 112 image size. Numbers in parentheses indicate the time when you use a normally charged battery.

- Battery life and no. of images will be decreased if you use the camera in a cold environment or while you repeat turning the power on/off and zooming.
- The capacity of a floppy disk is limited. The above figures are a guide when continuously recording/playing back while replacing the floppy disks.

Viewing images using a personal computer

With this camera, the still image data is compressed in JPEG format and move image data is compressed with MPEG-1 format. These data can be viewed using a personal computer which installed JPEG and MPEG browsing software as Microsoft Internet Explorer 4.0. For further information to use the browsing software, refer to the personal computer instruction manual.

Example: personal computer with Windows 95 installed

1 Start up personal computer and insert the floppy disk into the disk drive of the personal computer.

2 Open "My computer" and double click "3.5 inch FD (A:)".

3 Double-click the desired data file.

Recommended OS/applications example

OS
Windows 3.1, Windows 95 or later, Windows NT 3.51 or later, etc.

applications
Microsoft Internet Explorer 4.0, Netscape Navigator etc.

To display the image list, double-click "MAVICA.HTM" of the floppy disk recorded with this camera if your personal computer is installed with a browser such as Microsoft Internet Explorer.

⇨Recording and playing back images

Notes

- To play back an MPEG file, install Active Movie Player (Direct Show).
- For playing back a file recorded in MOVIE or VOICE mode, first copy it to the hard disk of the personal computer. If you play back the file from a floppy disk, the picture and sound may break off.
- You cannot play back an MPEG file with Windows 3.1.
- Opening non-compressed images recorded in BITMAP mode (p. 26, 27) requires an application program designed to view bitmapped images.
- For Macintosh, you can use the floppy disk recorded with this camera using the PC Exchange with Mac OS system 7.5 or higher. A viewing application for Macintosh is also necessary for viewing images. To play back an MPEG file, install Quick Time 3.0.

Changing the mode settings

1 Select "MENU" with the control button, then press it.

The menu appears on the LCD screen.



2 Select desired item with the control button, then press it.

When an item is selected, the color of the item changes from blue to yellow.



3 Change the setting with the control button, then press it.

When the setting is finished, the menu screen returns to the screen of step 1.



⇨Changing the mode settings

To cancel changing the mode settings

Press the left side of the control button. The screen returns to the menu screen. To cancel the menu screen, select "⮌" with the control button, then press it.

Setting the mode of each item

* is set at the factory.

Items in STILL mode

REC MODE <NORMAL*/E-MAIL/VOICE/BMP BITMAP>

- Normally select NORMAL. A JPEG file is recorded in selected image size.
- Select E-MAIL to record a 320 × 240 JPEG file besides a 640 × 480 (or 1024 × 768) JPEG file. E-mail files are suitable for e-mail transmission, etc. because they contain compressed data.
- Select VOICE to record a still image and sound together besides a JPEG file.
  Press the shutter button down momentarily.
  The sound is recorded for 5 seconds.
  Hold the shutter button down.
  The sound is recorded until you release it. (Maximum 40 seconds)
- Select BITMAP to record a non-compressed image (640 × 480) besides a JPEG file. This is good for recording images in clearer detail.

Recording mode	Image size	Recorded file	File name (ex.)** MVC-	No. of images that can be recorded on a floppy disk STANDARD	FINE
NORMAL	1024 × 768	JPEG (1024 × 768)	001L.JPG	10 – 16	6 – 8
		For index screen	001L.411		
	640 × 480	JPEG (640 × 480)	001S.JPG	25 – 40	15 – 20
		For index screen	001S.411		
E-MAIL	1024 × 768	JPEG (1024 × 768)	001L.JPG		
		JPEG (320 × 240)	001E.JPG	9 –14	5 – 7
		For index screen	001L.411		
	640 × 480	JPEG (640 × 480)	001S.JPG		
		JPEG (320 × 240)	001E.JPG	20 – 35	12 – 15
		For index screen	001S.411		
VOICE	1024 × 768	JPEG (1024 × 768)	001L.JPG		
		MPEG audio with still image (320 × 240)	001A.MPG	4 – 9	3 – 6
		For index screen	001L.411		
	640 × 480	JPEG (640 × 480)	001S.JPG		
		MPEG audio with still image (320 × 240)	001A.MPG	5 – 14	4 – 10
		For index screen	001S.411		
BITMAP*	1024 × 768	JPEG (1024 × 768)	001L.JPG		
		Non-compress (640 × 480)	001L.BMP	1	1
		For index screen	001L.411		
	640 × 480	JPEG (640 × 480)	001S.JPG		
		Non-compress (640 × 480)	001S.BMP	1	1
		For index screen	001S.411		

* The non-compressed image in BITMAP mode is 640 × 480 size regardless of IMAGE SIZE in the MENU settings.
** If you record images in FINE quality mode, the last character of file name will be "X" or "F". (ex. MVC-001X.JPG)

⇨Changing the mode settings

Notes

- The file data for index screen is a available only on this camera.
- If you attempt to record 55 images or above, "DISK FULL" appears on the LCD screen and you cannot record the image even when the remaining disk capacity indicator is not emptied.
- 320 × 240 size E-mail files are stored in another folder. The compression ratio is standard and does not depend on the image quality settings.
- A remaining capacity of about 1MB is needed when recording in BITMAP mode. After recording the BITMAP picture, "DISK FULL" appears on the LCD screen.
- The images recorded in VOICE mode are displayed one-size smaller than the other normal-sized images.
- When the remaining disk capacity indicator flashes, image and sound data cannot be recorded.

QUALITY <FINE/STANDARD*>

- Select FINE when giving priority to image quality.
- Select STANDARD as a standard image quality.

IMAGE SIZE <640 640 x 480/1024 1024 x 768*>

Select a size of JPEG still image.

FLASH LEVEL <HIGH/NORMAL*/LOW>

- Select HIGH to make the flash level higher than normal.
- Normally select NORMAL.
- Select LOW to make the flash level lower than normal.

Items in MOVIE mode

IMAGE SIZE <320 320 x 240/160 160 x 112*>

Select a size of MPEG moving image.

Image size	Recorded file	File name (ex.) MVC-	Recording time on a floppy disk* (sec.)
160 × 112	MPEG (160 × 112)	001V.MPG	60
	For index screen	001V.411	
320 × 240	MPEG (320 × 240)	001W.MPG	15
	For index screen	001W.411	

* Approximate continuous recording time.

Items for both STILL and MOVIE mode

FILE NUMBER <NORMAL*/SERIES>

- Select NORMAL to reset the numbering of files each time the floppy disk is changed.
- Select SERIES to put numbers to files in sequence even if the floppy disk is changed.

DEMO MODE <STANDBY/ON* or OFF>

Only when you use the AC power adaptor (not supplied), DEMO MODE appears in the menu.

- Select ON to make the demonstration appear. The demonstration will start about 10 minutes after the power is turned on if the camera has not been operated.
- Select OFF to deactivate the demonstration mode.

Note

To stop the demonstration, turn off the camera.

⇨ Changing the mode settings

Items in PLAY mode

PROTECT

Select this item to protect a displayed image(s) from being deleted by mistake.
To protect or unprotect an image file, select the desired option from the menu while the image is displayed on the LCD screen.

In SINGLE screen mode

<ON/OFF*>
- Select ON to protect displayed image.
- Select OFF to release protection of the image.

In INDEX screen mode

<ALL/SELECT>
- Select ALL to protect all images recorded with this camera.
- Select SELECT to protect selected images.

① **Use the control button to display the red ▶ mark at the image you want to protect.**
The selected image number reverses color. To cancel selection, press the control button again. The image number returns to normal.

② **Select "ENTER" with the control button, then press it.**
🔑 appears on the upper left side of the image.

To cancel protection of the images in INDEX screen mode, select the images you want to cancel protection in step ①, then press the control button.
The "🔑" indicator at the upper left side of the image disappears.
When you have finished the cancelling, select "ENTER" with the control button, then press it.

To cancel protecting image, select "CANCEL" with the control button, then press it. The screen returns to the menu screen.

COPY

Select this item to copy a displayed image(s) to another floppy disk.
To copy an image(s), select the desired copy option from the menu while the image(s) is displayed on the LCD screen.

In SINGLE screen mode

<OK/CANCEL>
- Select OK to copy displayed image.
- Select CANCEL to cancel copying image.

In INDEX screen mode

<ALL/SELECT>
- Select ALL to copy all images recorded with this camera.
- Select SELECT to copy selected images.

① **Use the control button to display the red ▶ mark at the image you want to copy.**
The selected image number reverses color. To cancel selection, press the control button again. The image number display returns to normal.

② **Select "ENTER" with the control button, then press it.**

To cancel copying image, select "CANCEL" with the control button, then press it. The screen returns to the menu.

To copy to another floppy disk

1 **In SINGLE screen mode, select "OK". Or In INDEX screen mode, select "ALL", then "OK" or select "SELECT", then carry out steps ① and ② above.**
"CHANGE FLOPPY DISK" will be displayed.

2 **Eject the floppy disk.**
"INSERT FLOPPY DISK" will be displayed.

3 **Insert another floppy disk until you hear it click.**
"DISK ACCESS" will be displayed.

⇨ Changing the mode settings

4 **Once copying is completed, the message "COMPLETE" is displayed.**
To copy images to another floppy disk, select "CONTINUE" with the control button and repeat the operations in steps 2 through 4 above.
To discontinue copying, select "EXIT" with the control button.

Notes
- When you copy to the floppy disk which is a small remaining capacity, "DISK FULL" may appear on the LCD screen.
- To discontinue copying onto a floppy disk halfway (in the middle of steps 1 to 4 above), change PLAY/STILL/MOVIE or turn off the camera.

DELETE

Select this item to delete a displayed image(s).
To delete an image(s), select the desired delete option from the menu while the image(s) is displayed on the LCD screen.

In SINGLE screen mode

<OK/CANCEL>
- Select OK to delete displayed image.
- Select CANCEL to cancel deleting image.

In INDEX screen mode

<ALL/SELECT>
- Select ALL to delete all images recorded with this camera.
- Select SELECT to delete selected images.

① **Use the control button to display the red ▶ mark at the image you want to delete.**
The selected image number reverses color. To cancel selection, press the control button again. The image number display returns to normal.

② **Select "ENTER" with the control button, then press it.**

To cancel deleting image, select "CANCEL" with the control button, the press it. The screen returns to the menu screen.

Notes
- Once deleted an image cannot be restored. Before deleting, carefully check the images you intend to delete.
- Even when you select "ALL", you cannot delete the protected image.
- When you select "SELECT", you cannot select a protected image.

Items for STILL, MOVIE and PLAY modes

DISK TOOL <FORMAT/DISK COPY>

- Select FORMAT to format the floppy disk loaded in the camera.
- Select DISK COPY to copy all data stored in a floppy disk to another.

To copy all data stored in a floppy disk to another

1 **Select "DISK COPY", then "OK".**
"FILE ACCESS" will be displayed.

2 **When "CHANGE FLOPPY DISK" is displayed, eject the floppy disk.**

3 **When "INSERT FLOPPY DISK" is displayed, insert another disk.**
"DISK ACCESS" will be displayed.

4 **Once copying is completed, the message "COMPLETE" is displayed.**
To copy images to another floppy disk, select "CONTINUE" with the control button and repeat the operations in steps 2 through 4 above.
To discontinue copying, select "EXIT" with the control button.

Notes
- To discontinue copying onto a floppy disk halfway (in the middle of steps 1 to 4 above), change PLAY/STILL/MOVIE or turn off the camera.
- Formatting erases all information on the floppy disk, and with copying disk, all information saved on the recipient floppy disk are erased to be replaced by newly written data including the protected image data. Check the contents of the disk before formatting and copying disk.
- Be sure that the battery is fully charged when formatting and copying a floppy disk. Formatting and copying takes about 1 minutes maximum.
- Be sure to use the formatted floppy disk to carry out DISK COPY.

BEEP <ON*/OFF>

- Normally select ON.
- Select OFF to turn the beep/shutter sound off.

CLOCK SET

Select this item to set the date and time. See page 13.

Using various functions for recording



Focusing manually

1 Set FOCUS AUTO/MANU to MANU.

☞ appears on the LCD screen.

2 Turn the focus ring to achieve a sharp focus.

The position marked " ▸●◂ " indicates the area in focus.

To reactivate auto focusing, set FOCUS AUTO/MANU to AUTO.

Notes

- When recording in relatively dark environment, it is recommended to record after focusing manually, or set PROGRAM AE to Panfocus mode.
- When you focus manually in dark environment " ▸●◂ " may not be displayed.

Enjoying Picture Effect

Press PICTURE EFFECT repeatedly to select the desired picture effect mode.

NEG. ART: The color and brightness of the picture is reversed.
SEPIA: The picture is sepia.
B&W: The picture is monochrome (black and white).
SOLARIZE: The light intensity is more clear, and the picture looks an illustlation.

To cancel picture effect

Press PICTURE EFFECT repeatedly until the indicator on the LCD screen goes out. When you turn the power off or set PLAY/STILL/MOVIE to PLAY, the picture effect is automatically cancelled.

⇨Using various functions for recording

Using the PROGRAM AE function

You can select one of six PROGRAM AE (Auto Exposure) modes to suit your shooting situation, referring to the following.

Press PROGRAM AE repeatedly to select the desired PROGRAM AE mode.

Soft Portrait mode
Creates a soft background for subjects such as people or flowers, and faithfully reproduces skin color.

Sports Lesson mode
For recording fast-moving subjects such as in tennis or golf games.

Beach & Ski mode
For people or faces in strong light or reflected light, such as at a beach in midsummer or on a ski slope.

Sunset & Moon mode
For recording subjects in dark environments such as sunsets, fireworks, neon signs, or general night views.

Landscape mode
For distant subjects such as mountains or when recording a subject behind an obstacle such as a window or screen.

Panfocus mode
For recording close or distant subjects quickly and simply. Or, for recording with flash in a dark place where it is hard to bring the camera into focus.

To cancel PROGRAM AE

Press PROGRAM AE repeatedly until the indicator on the LCD screen goes out.

Notes on focus settings

- You cannot take close-ups in Sports Lesson and Beach & Ski modes.
- You can focus only on distance subjects in Sunset & Moon and Landscape modes.
- In Panfocus mode, the zoom position and focus are fixed.

Changing the lithium battery in the camera

When the lithium battery becomes weak or dead, the "⚠" indicator flashes on the LCD screen. In this case, replace the battery with a Sony CR2025 or Duracell DL-2025 lithium battery. Use of any other battery may present a risk of fire or explosion.
When installing the lithium battery, keep the battery pack attached. Otherwise, you will need to reset the date and time retained by the lithium battery.

1 Slide the lid of the lithium battery compartment and open it.



2 Push the lithium battery once and push it out from the holder.

3 Install the lithium battery with the positive (+) side facing out.

4 Close the lid.

WARNING
The battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

CAUTION
Danger of explosion if battery is incorrectly replaced.
Replace only with the same type recommended by the manufacturer.
Discard used batteries according to the manufacturer's instructions.

Precautions

On cleaning

Cleaning the LCD screen

Wipe the screen surface with a LCD cleaning kit (not supplied) to remove fingerprints, dust, etc.

Cleaning the camera surface

Clean the camera surface with a soft cloth slightly moistened with water. Do not use any type of solvent such as alcohol or benzene as it may mar the finish of the casing.

Using the camera on a sandy beach or in a dusty place

Do not let sand get into the camera. Sand or dust may cause the unit to malfunction, and sometimes this malfunction cannot be repaired.

Concerning floppy disks

To protect data recorded on floppy disk, note the following:

- Avoid storing floppy disks near magnets or magnetic fields such as those of speakers and televisions, permanent erasure of disk data may result.
- Avoid storing floppy disks in areas subject to direct sunlight or sources of high temperature, such as a heating device. Floppy disk warping or damage may result, rendering the disk useless.
- Avoid contact with the disk's surface by opening the disk shutter plate. If the disk's surface becomes blemished, data may be rendered unreadable.
- Avoid getting liquids on the floppy disk.
- Be sure to use a floppy disk case to ensure protection of important data.
- Use only a 2HD type disk head cleaner when cleaning the disk drive.
- Even when you use a 3.5 inch 2HD floppy disk, image data may not be recorded and/or displayed depending on the using environment. In this case, use other brand disks.

Operational temperature recommendations

This camera's operational temperature is between 32°F to +104°F (0°C to +40°C). Do not use this camera in extreme climates outside the operational temperature range.

Moisture condensation

If the camera is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense inside or outside the camera. Should this occur, the camera will not operate properly. In this case, remove the floppy disk, turn off the camera, and wait about an hour for the moisture to evaporate.

To prevent moisture condensation

When bringing the camera from a cold place to a warm place, put the camera in a plastic bag and allow it to adapt to room conditions over a period of time.

① Be sure to tightly seal the plastic bag containing the camera.
② Remove the bag when the air temperature inside it has reached the temperature surrounding it (about 1 hour).

Notes on lithium battery

- Keep the lithium battery out of the reach of children. Should the battery be swallowed, immediately consult a doctor.
- Wipe the battery with a dry cloth to assure a good contact.
- Do not hold the battery with metallic tweezers, otherwise a short-circuit may occur.
- Note that the lithium battery has a positive (+) and a negative (–) terminal. Be sure to install the lithium battery so that symbols on the battery match the symbols on the camera.

Troubleshooting

Should any problem persist after you have made those checks, consult your nearest Sony dealer. **If "C: □□: □□" appears on the LCD screen, the self-diagnosis function has worked. See page 42.**

Symptom	Cause and/or Solution
The camera does not work.	• The camera does not operate when using a battery pack that is not an "InfoLITHIUM" battery pack. → Use an "InfoLITHIUM" battery pack. (p. 13) • The floppy disk is not installed properly. → Remove the disk and reinstall it. (p. 8)
You cannot record images.	• PLAY/STILL/MOVIE is not set to STILL or MOVIE. → Set it to STILL or MOVIE. (p. 16, 17) • No floppy disk has been installed. → Installe a formatted floppy disk. • The tab on the disk is set to the non-recording position. → Set it to the recording position. (p. 8)
The picture is noisy.	• The camera is placed near a TV or other equipment that uses strong magnets. → Place the camera away from the TV, etc.
The picture is too dark.	• You are shooting a subject with the light source behind the subject or light is insufficient. → Adjust brightness of the image. (p. 9) • The LCD screen adjustment is too dark. → Adjust brightness. (p. 9)
The flash does not work.	• The no flash mode is set. → Set it to the AUTO or forced-flash mode. (p. 10)
Incorrect date and time are recorded.	• The date and time are not set. → Set the date and time. (p. 13)
Vertical streaks appear when shooting a very bright subject.	• The smear phenomenon. → The camera is not malfunctioning.

Symptom	Cause and/or Solution
The battery life deteriorates too fast.	• The ambient temperature is too low. • Charging of the battery pack is not enough. → Charge the battery pack fully. • The battery pack has served its time. → Replace the battery pack with a new one.
Zoom does not work.	• Panfocus mode in PROGRAM AE is working. → Cancel it. (p. 36)
You cannot play back the images on the LCD screen.	• PLAY/STILL/MOVIE is not set to PLAY. → Set it to PLAY. (p. 19) • The battery is dead. → Use a charged battery pack.
The picture and sound break off when you play back the images using a personal computer.	• The image file is on a floppy disk. → Copy to the hard disk of a personal computer. Then play back the image from the hard disk. (p. 24)
You cannot play back the image using a personal computer.	• Contact your personal computer maker or software maker.
You cannot delete an image.	• The image is protected. → Cancel the protection of the image. (p. 30)
The power turns off automatically.	• If you leave the camera inactive in STILL/MOVIE mode for about 3 minutes while the power is on, it turns off automatically to prevent wearing down the battery. → Turn the power on.

Self-diagnosis display

The camera has a self-diagnosis display. This function displays the camera condition with five-digits (a combination of a letter and figures) on the LCD screen. If this occurs check the following code chart. The five-digit display informs you of the camera's current condition. The last two digits (indicated by □□) will differ depending on the state of the camera.



Self-diagnosis display

- C: □□: □□
  You can reverse the camera malfunction yourself.
- E: □□: □□
  Contact your Sony dealer or local authorized Sony service facility.

First three digits	Cause and/or Corrective Action
C:32:□□	• Trouble is with the disk drive. →Turn the power off and on again.
C:13:□□	• An unformatted disk is installed. →Format the disk. (p. 33) • An unusable disk with the camera is installed. →Change the disk. (p. 8)
E:91:□□ E:61:□□	• A camera malfunction which you can not reverse has occurred. →Contact your Sony dealer or local authorized Sony service facility and inform them of the five digits. (example: E:61:10)

⇨ Specifications

Warning messages

Various messages appear on the LCD screen. Check them with the following list.

Message	Meaning
DRIVE ERROR	Trouble is with the disk drive.
NO DISK	No disk has been inserted.
DISK ERROR	Trouble is with the disk. Or the floppy disk loaded is not MS-DOS formatted (512 bytes x 18 sectors).
DISK PROTECT	The tab on the disk is set to the non-recording position.
DISK FULL	The disk is full.
NO FILE	No image has been recorded on the disk.
FILE ERROR	Trouble has occurred during playback.
FILE PROTECT	The image is protected.
⌧	The battery is weak.
⌧	The lithium battery is weak or is not installed.

SECTION 2
DISASSEMBLY

NOTE: The following flow chart shows the disassembly procedure.


MVC-FD81 MAVICA
2-1. ①-⑪ Cabinet (front) block assembly
2-2. ①-③ DD-119 board
2-2. ④,⑤ FC-67 board
2-2. ⑥-⑪ Floppy disk drive
2-4. ①-③ MF block (50080)
2-4. ④-⑩ RL-51 board
2-4. ⑪-⑯ FLASH unit
2-1. ⑫-⑭ Lens block assembly
2-5. ①,② CD-206 board
2-5. ③-⑤ Lens device
2-1. ⑮-⑲ Cabinet (rear) block assembly
2-3. ①-③ LCD, Backlight
2-3. ④,⑤ LCD
2-3. ⑥-⑧ PK-44 board
2-3. ⑩-⑫ Speaker

NOTE: Follow the disassembly procedure in the numerical order given.

2-1. CABINET (FRONT) ASSEMBLY, CABINET (REAR) ASSEMBLY


①-⑪ Cabinet (front) block assembly
⑫-⑭ Lens block assembly
⑮-⑲ Cabinet (rear) block assembly
⑰ Flexible board (From CN601 18P, PK-44 board)
⑧ Connector (From CN702 7P, FC-67 board)
② Two screws, lock ace (M2 × 4)
⑨ Connector (From CN704 13P, FC-67 board)
③ Screw, lock ace (M2 × 4)
⑩ Connector (From CN301 4P, DD-119 board)
⑦ Claws
⑲ Cabinet (rear) block assembly
⑮ Tapping screw (B2 × 5)
⑬ FP-66 flexible board (From CN101 16P, FC-67 board)
⑭ Lens block assembly
PK-44 Board
FC-67
DD-119
a
⑫ Flexible board (From CN401 20P, FC-67 board)
⑥ Screw, lock ace (M2 × 4)
① Screw, lock ace (M2 × 4)
a
⑯ Connector (From CN602 70P, FC-67 board)
⑪ Cabinet (front) block assembly
⑱ Two flexible boards (From CN602 5P × 2, PK-44 board)
⑤ Screw, lock ace (M2 × 4)
④ Two screws, lock ace (M2 × 4)

2-2. FC-67 BOARD, DD-119 BOARD, FLOPPY DISK DRIVE



2-3. PK-44 BOARD, LCD PANEL



2-4. RL-51 BOARD, FLASH UNIT


①-③ MF block (50080)
④-⑩ RL-51 board
⑪ RL holder
⑫-⑯ FLASH unit
⑫ Connector (From CN1 13P, FLASH unit)
② Three screws, tapping (B2 × 5)
⑮ Fuse replacement caution label
⑯ FLASH unit
③ MF block (50080)
⑭ Release the claw
⑬ Screw, tapping (B2 × 5)
① MF block (50080) Flexible board (From CN2 6P, FLASH unit)
⑧ Connector (From CN001 2P, RL-51 board)
⑦ Connector (From CN002 7P, RL-51 board)
⑩ RL-51 board
⑨ Release the claws
④ Three screws, tapping (B2 × 5)
⑪ RL holder
⑥ Ground plate (A)
⑤ Charging capacitor of FLASH unit
Short jig (see page 5) (1kΩ. 1W parts.No.1-215-869-11)
When handling the FLASH unit, be sure to discharge the charging capacitor before handling it. For discharge short jig to the positive (+) and negetive (-) terminals of the charging capacitor for about ten seconds.

2-5. CD-206 BOARD, LENS DEVICE


② Two screws, tapping (B2 × 7.5)
③ CD-206 board
⑤ Lens frame
CD sheet (Not supplied)
⑥ Lens device
Prism cushion (Not supplied)
① FP-66 flexible board (From CN431 16P, CD-206 board)
④ Two screws, tapping (B2 × 5)

Be sure to read “Note on the CCD imager replacement” on page 4-7 when changing the CCD Imager.

2-6. SERVICE POSITION (Routing and location of harnesses)



Procedure

① *Route the harness that comes from CN301 of the DD-119 board, around the corner (Ⓒ in the figure) of IC851 (FC-67 board) and the side (Ⓑ in the figure) of CN702.*
② *Fix the DC CUSHION (2) at the specified position. (*1)*
③ *Fix the ST SHIELD PLATE at the specified position. (*1)*
④ *Route the harness as shown (Ⓐ in the figure).*

*(*1) Aligning the position of the FC CUSHION (2) and ST SHIELD PLATE*



○ *Align the FC CUSHION (2) with the lines A and B as shown.*
○ *Align the ST SHIELD PLATE with the lines B and C as shown.*

2-7. SERVICE POSITION (For voltage measurement)

Firstly, remove the following parts referring to DISASSEMBLY (sections 2-1 to 2-4), and connect parts as shown below.



2-8. CIRCUIT BOARDS LOCATION







SECTION 3
BLOCK DIAGRAMS

3-1. OVERALL BLOCK DIAGRAM



3-2. CAMERA/FDD INTERFACE BLOCK DIAGRAM



3-3. MODE CONTROL BLOCK DIAGRAM



3-4. LCD BLOCK DIAGRAM



3-5. POWER BLOCK DIAGRAM



SECTION 4
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. FRAME SCHEMATIC DIAGRAM



FRAME SCHEMATIC DIAGRAM

4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

THIS NOTE IS COMMON FOR WIRING BOARDS AND SCHEMATIC DIAGRAMS
(In addition to this, the necessary note is printed in each block)

(For printed wiring boards)
- ▒▒: Pattern from the side which enables seeing. (The other layers' patterns are not indicated.)
- Through hole is omitted.
- Circled numbers refer to waveforms.
- There are few cases that the part printed on diagram isn't mounted in this model.
- Chip parts.

Transistor



Diode



(For schematic diagrams)
- All capacitors are in µF unless otherwise noted. pF : µµF. 50V or less are not indicated except for electrolytics and tantalums.
- Chip resistors are 1/10W unless otherwise noted. kΩ=1000Ω, MΩ=1000kΩ.
- Caution when replacing chip parts. New parts must be attached after removal of chip. Be careful not to heat the minus side of tantalum capacitor, Because it is damaged by the heat.
- Some chip part will be indicated as follows.

Example	C541	L452
	22U	10UH
	TA A	2520

Kinds of capacitor
Temperature characteristics
External dimensions (mm)

- Constants of resistors, capacitors, ICs and etc with XX indicate that they are not used. In such cases, the unused circuits may be indicated.
- Parts with ★ differ according to the model/destination. Refer to the mount table for each function.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Signal name
  XEDIT → $\overline{\text{EDIT}}$ PB/XREC → PB/$\overline{\text{REC}}$
- : non flammable resistor
- : fusible resistor
- : panel designation
- : B+ Line *
- : B– Line *
- : IN/OUT direction of (+,–) B LINE. *
- : adjustment for repair. *
- Circled numbers refer to waveforms. *

* Indicated by the color red.

Note :	**Note :**
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

(Measuring conditions voltage and waveform)
- Voltages and waveforms are measured between the measurement points and ground when camera shoots color bar chart of pattern box. They are reference values and reference waveforms. * (VOM of DC 10 MW input impedance is used.).
- Voltage values change depending upon input impedance of VOM used.) *

1. Connection



2. Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.



Fig. a (CPC-9 jig TP-VG output waveform)



Fig.b (Picture on LCD)

When indicating parts by reference number, pleas include the board name.

CD-206 (CCD IMAGER) PRINTED WIRING BOARD
— Ref. No. CD-206 Board; 2,000 Series —



CD-206 BOARD

C431	A-4	L431	B-4
C432	B-3		
C433	A-4	Q431	B-4
C434	B-3		
C435	A-3	R431	B-3
C436	A-4	R432	B-4
		R433	B-4
CN431	B-4	R434	A-4
		R435	A-3
IC431	A-1	R436	A-3

For printed wiring boards
- This board is six-layer print board. However, the patterns of layers two to five have not been included in the diagram.
- Chip parts

Transistor

There are few cases that the part printed on this diagram isn't mounted in this model.


PK-44
REC/PB AMP, LCD DRIVE, TIMING GENERATOR, BACK-LIGHT DRIVE, MODE KEY SWITCH
CD-206
(CCD IMAGER)
FC-67
CAMERA Y/C PROCESS, DRAM CONTROL, LENS MOTOR DRIVE, D/A CONVERTER, AUDIO A/D D/A CONVERTER, FD/SYSTEM CONTROL, HI CONTROL



•SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC			→
PB			

Precautions Upon Replaching CCD imager

- The CD-206 board mounted as a repair part is not equipped with a CCD imager.
  When replaching this board, remove the CCD imager from the old one and mount it onto the new one.
- If the CCD imager has been replaced, carry out all the adjustments for the camera section.
- As the CCD imager may be damaged by static electrictiy from its structure, handle it carefully like for the MOS IC.
  In addition, ensure that the receiver is not covered with dusts nor exposed to strog light.

CD-206 BOARD

CAMERA REC

① IC431 ①,③

② IC431 ②,④



③ IC431 ⑧



④ IC431 ⑮,⑯



⑤ IC431 ⑭



FC-67 BOARD (SIDE A)

C001	A-3	C865	E-2	R012	A-2	R740	B-5
C002	B-3	C866	E-4	R013	A-2	R741	B-5
C003	A-3	C867	C-1	R014	B-2	R742	A-4
C004	B-3	C868	D-4	R015	B-2	R743	B-5
C005	B-2	C869	E-4	R016	B-2	R744	A-4
C006	A-1	C870	E-4	R018	A-2	R745	B-5
C007	A-1	C871	E-4	R019	B-2	R746	D-4
C008	A-2	C872	E-4	R026	B-1	R747	B-4
C009	B-2	C873	E-4	R027	B-2	R748	B-4
C010	A-2	C874	D-4	R028	B-1	R749	C-2
C011	A-2	C875	D-4	R029	B-1	R751	C-2
C028	B-2			R030	A-2	R752	A-4
C029	A-2	CN001	G-2	R031	A-3	R753	A-4
C030	B-2	CN101	F-4	R032	A-2	R754	D-4
C031	B-2	CN401	G-4	R033	B-1	R755	D-4
C032	B-2	CN601	E-6	R034	B-1	R756	F-4
C037	A-2	CN602	A-4	R038	A-1	R758	F-4
C111	F-3	CN603	C-1	R041	B-1	R759	B-2
C112	F-2	CN701	F-4	R042	B-1	R760	F-4
C116	F-3	CN702	G-1	R111	F-2	R761	B-3
C117	F-3	CN703	A-6	R119	G-2	R762	B-3
C119	F-3	CN704	G-3	R122	F-3	R763	B-3
C120	F-3			R124	F-3	R764	B-3
C121	F-3	D001	A-5	R125	F-3	R765	B-3
C122	F-3	D002	G-4	R135	G-2	R766	B-3
C123	F-3	D003	E-1	R136	G-2	R769	B-3
C124	F-3	D701	C-2	R137	G-2	R770	G-3
C125	F-3	D702	B-2	R401	F-4	R771	G-3
C126	G-2	D703	C-2	R403	G-3	R772	G-3
C127	G-3	D705	B-2	R404	G-3	R773	A-4
C131	F-3	D706	E-3	R405	G-3	R774	B-5
C132	F-2			R430	G-4	R775	C-5
C135	G-2	FB102	F-3	R602	D-6	R776	C-3
C401	F-4	FB801	C-2	R603	D-6	R777	C-3
C405	G-4	FB803	C-1	R604	D-6	R778	E-3
C407	G-4			R607	D-6	R779	A-5
C409	G-4	IC001	A-1	R608	D-6	R780	A-5
C411	G-4	IC005	A-2	R609	D-6	R781	C-2
C412	G-3	IC006	A-3	R625	D-6	R784	G-1
C417	G-3	IC101	F-3	R626	D-6	R785	G-2
C701	C-2	IC103	F-2	R627	A-5	R786	G-2
C702	C-2	IC402	G-4	R628	A-5	R824	E-4
C703	B-2	IC403	G-3	R701	B-2	R828	D-4
C704	C-2	IC701	C-2	R702	B-2	R855	E-2
C705	B-2	IC702	C-4	R704	C-2	R856	E-4
C706	B-2	IC703	C-3	R705	D-4	R857	E-4
C707	B-2	IC704	E-5	R706	D-4	R858	E-4
C708	C-3	IC851	D-3	R707	C-3	R863	D-4
C709	B-3	IC852	D-1	R708	C-3	R868	C-1
C710	C-5			R709	C-3	R871	E-4
C711	C-5	L001	B-3	R710	B-3	R876	C-2
C712	C-5	L002	B-3	R711	B-3	R877	C-2
C713	B-5	L004	B-1	R712	D-4	R878	C-2
C714	A-3	L102	G-2	R713	B-3	R879	C-3
C715	A-4	L401	G-3	R714	D-4	R880	C-3
C716	B-4	L402	G-3	R715	C-5	R881	C-3
C717	B-4	L701	B-2	R716	B-5	R882	C-3
C718	C-2	L702	E-4	R717	C-4	R883	C-3
C719	C-5	L703	D-5	R718	C-3	R884	C-3
C722	B-5	L802	C-2	R719	A-5	R885	E-4
C724	B-2	L803	C-1	R720	B-5	R886	E-1
C725	B-3			R721	C-4	R888	E-4
C726	B-3	Q401	G-3	R722	C-4	R889	E-4
C727	B-2	Q701	B-2	R723	C-4	R890	E-4
C728	A-5	Q702	B-2	R724	C-4	R891	E-4
C729	A-5	Q703	A-4	R725	C-4	R892	E-3
C730	B-5	Q704	B-4	R726	A-5	R893	E-3
C731	B-5	Q705	B-4	R727	A-5	R894	E-2
C732	E-4	Q706	E-3	R728	A-5	R895	E-2
C733	D-5	Q707	B-3	R729	A-5	R896	E-4
C734	D-4	Q708	B-3	R730	C-3	R897	E-2
C735	E-4	Q804	E-1	R731	B-5	R898	E-2
C736	F-4	Q1005	B-1	R732	B-3	R899	E-1
C821	C-2			R733	F-4		
C853	D-2	R006	A-3	R734	E-4	X701	C-3
C856	C-3	R007	A-2	R735	B-3	X702	B-4
C858	D-4	R008	B-3	R736	B-3	X802	D-4
C859	D-4	R009	A-1	R737	A-5		
C861	D-4	R010	B-2	R738	A-5		
C862	D-4	R011	A-1	R739	A-5		

FC-67 (CAMERA Y/C PROCESS, DRAM CONTROL, LENS MOTOR DRIVE, D/A CONVERTER, AUDIO A/D.D/A CONVERTER, FD/SYSTEM CONTROL, HI CONTROL) PRINTED WIRING BOARD

— Ref. No. FC-67 Board; 10,000 Series —

FC-67 BOARD (SIDE A)



FC-67 BOARD (SIDE B)



FC-67 BOARD (SIDE B)

C012	G-13	C607	A-10	L451	D-11	R423	G-11
C013	G-13	C608	A-10	L452	A-11	R424	G-11
C014	G-13	C609	A-10	L601	B-9	R425	G-11
C015	G-13	C610	A-9	L602	A-10	R426	G-11
C016	G-13	C611	A-9	L603	A-10	R428	G-11
C017	G-13	C612	A-9	L604	A-9	R429	G-11
C019	G-12	C720	C-9	L801	D-13	R431	G-10
C020	G-12	C721	B-10			R451	E-11
C021	G-13	C804	B-13	Q101	G-11	R452	F-12
C022	G-12	C805	D-13	Q102	G-11	R453	F-12
C023	G-12	C806	B-13	Q103	G-11	R454	F-12
C024	F-12	C807	D-13	Q104	G-11	R455	F-11
C025	G-12	C808	D-13	Q402	G-9	R456	E-13
C026	G-12	C809	D-13	Q403	G-10	R457	C-11
C027	F-12	C810	D-12	Q601	A-10	R601	A-9
C033	G-12	C811	B-13	Q602	A-10	R605	A-10
C034	G-12	C812	A-13	Q603	A-9	R606	A-9
C035	G-13	C813	A-13	Q801	A-13	R610	A-10
C102	G-11	C814	A-12	Q802	D-11	R611	A-10
C103	F-10	C815	E-13	Q803	D-11	R612	A-10
C104	E-10					R613	A-10
C107	E-10	FB101	F-11	R017	G-12	R614	A-10
C108	F-11	FB103	F-11	R020	G-13	R615	A-9
C109	F-11	FB451	D-11	R021	G-13	R616	A-9
C110	G-10	FB452	D-13	R022	G-13	R617	A-9
C113	F-10	FB453	E-13	R023	G-13	R618	A-9
C114	F-10	FB454	F-12	R024	G-13	R619	A-9
C128	G-12	FB455	F-11	R025	F-13	R620	A-9
C129	G-11	FB456	E-11	R035	G-12	R621	A-9
C130	F-10	FB457	D-12	R036	G-12	R622	A-9
C133	E-10	FB481	B-11	R037	G-12	R623	A-9
C134	E-10	FB482	E-9	R039	F-12	R624	A-9
C137	G-12	FB483	C-10	R040	G-13	R629	B-10
C138	G-10	FB484	E-10	R102	F-11	R630	A-10
C139	G-10	FB485	C-10	R103	E-10	R757	C-9
C402	G-9	FB486	B-10	R104	G-10	R802	B-12
C403	G-10	FB487	B-11	R106	F-11	R803	B-12
C404	G-10	FB488	C-11	R112	G-11	R804	B-12
C406	G-10	FB489	C-10	R113	G-11	R805	B-12
C408	G-10	FB490	D-12	R115	E-10	R806	B-12
C410	G-10	FB491	D-12	R116	E-10	R807	B-12
C413	G-10	FB802	E-13	R117	G-11	R808	C-12
C414	G-11			R118	G-11	R809	B-13
C415	G-11	IC002	G-12	R120	G-11	R810	B-13
C416	G-11	IC003	G-13	R121	F-11	R811	A-12
C418	G-11	IC004	G-13	R127	G-11	R812	D-13
C419	G-10	IC102	F-10	R128	G-11	R813	D-13
C420	G-10	IC104	G-12	R132	F-11	R814	D-13
C421	G-11	IC401	G-10	R133	F-11	R815	D-13
C451	C-11	IC404	G-10	R134	F-11	R816	C-12
C452	C-10	IC405	G-11	R138	G-11	R817	C-12
C453	F-12	IC451	D-10	R139	G-12	R818	C-12
C454	D-12	IC452	D-11	R140	G-10	R819	C-12
C455	C-10	IC453	E-12	R141	G-11	R820	C-12
C456	E-11	IC481	B-11	R402	G-9	R821	C-12
C457	E-13	IC601	B-9	R406	G-9	R822	C-12
C458	D-13	IC705	B-9	R407	G-10	R823	C-12
C459	F-11	IC801	C-12	R408	G-9	R825	A-13
C481	B-11	IC802	A-12	R409	G-10	R826	A-13
C482	B-11	IC803	A-13	R410	G-10	R827	A-13
C483	B-11	IC804	D-13	R411	G-10	R830	A-12
C484	A-11	IC805	A-12	R412	G-10	R831	A-12
C485	C-10	IC852	D-1	R413	G-10	R832	A-12
C486	E-9			R414	G-10	R870	B-12
C487	E-10	L003	F-12	R415	G-10	R887	D-11
C488	C-11	L005	G-13	R416	G-11		
C601	B-9	L007	F-12	R417	G-11	SE801	A-12
C602	B-9	L101	G-12	R418	G-11		
C603	A-9	L103	G-12	R419	G-10	X101	F-10
C604	A-9	L104	G-12	R420	G-11	X451	F-11
C605	A-10	L105	G-11	R421	G-11	X803	B-12
C606	A-9	L403	G-11	R422	G-11		

For printed wiring boards

- This board is six-layer print board. However, the patterns of layers two to five have not been included in the diagram.
- Chip parts

Transistor

There are few cases that the part printed on this diagram isn't mounted in this model.


PK-44
REC/PB AMP, LCD DRIVE, TIMING GENERATOR, BACK-LIGHT DRIVE, MODE KEY SWITCH
CD-206
(CCD IMAGER)
FC-67
CAMERA Y/C PROCESS, DRAM CONTROL, LENS MOTOR DRIVE, D/A CONVERTER, AUDIO A/D,D/A CONVERTER, FD/SYSTEM CONTROL, HI CONTROL

For schematic diagram
• Refer to page 4-9 for printed wiring board.

FC-67 BOARD (1/7)

① IC101 ② – ⑪
CAMERA REC/PB

② IC101 ⑯
CAMERA REC/PB

③ IC101 ㉘ CAMERA REC

④ IC102 ④
CAMERA REC/PB

⑤ IC102 ㉕
CAMERA REC/PB

⑥ IC103 ㊱,㊺
CAMERA REC/PB



For schematic diagram
• Refer to page 4-9 for printed wiring board.



For schematic diagram

• Refer to page 4-9 for printed wiring board.



For schematic diagram
• Refer to page 4-9 for printed wiring board.



FC-67 BOARD (4/7)
CAMERA REC/PB



For schematic diagram

• Refer to page 4-9 for printed wiring board.



For schematic diagram
• Refer to page 4-9 for printed wiring board.



FC-67 BOARD (6/7)
CAMERA REC/PB

⑨ IC801 ㉝
16.26MHz 5.0Vp-p

⑩ IC851 ㊽
7.41MHz 1.8Vp-p

FD/SYSTEM CONTROL
FC-67 (6/7)

For schematic diagram
• Refer to page 4-9 for printed wiring board.

FC-67 BOARD (7/7)
CAMERA REC/PB

⑦ IC702 ㊽
20MHz 4.0Vp-p

⑧ IC702 ㊾
32.768kHz 3.4Vp-p


FC-67 BOARD(7/7)
HI CONTROL
-REF.NO.:10000 SERIES-
XX MARK:NO MOUNT
NO MARK:REC/PB MODE
R :REC MODE
P :PB MODE
IC701
RESET
IC702
HI CONTROL
IC703
EEP ROM
IC704
EVR
IC705
CHARACTER GENERATOR
FLASH UNIT
CONTROL SWITCH BLOCK (MF UNIT)
FLASH UNIT and CONTROL SWITCH BLOCK is replaced as a block, so that these SCHEMATIC DIAGRAM and PRINTED WIRING BOARD are omitted.
Note: The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.
Note: Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
•SIGNAL PATH
AUDIO SIGNAL
REC
PB
(SEE PAGE 4-64)

For schematic diagram
• Refer to page 4-51 for printed wiring board.

PK-44 BOARD (1/5)

REC/PB AMP, MOTOR DRIVE (FD BLOCK)

-REF. NO. : 2000 SERIES-
XX MARK : NO MOUNT

NO MARK : REC/PB MODE
R : REC MODE
P : PB MODE



•SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	⇒	⇒	⇒	
PB	⇨	⇨	⇨	⇨

PK-44 BOARD (1/5)

① IC601 ㊷
CAMERA REC/PB

4.0MHz 3.2Vp-p

TO FC-67 BOARD (4/7) CN602 (THROUGH THE FP-65 FLEXIBLE)
(SEE PAGE 4-27)

For schematic diagram
• Refer to page 4-51 for printed wiring board.

PK-44 BOARD (2/5)
CAMERA REC/PB

② IC802 ⑧

③ IC802 ⑨


④ IC802 ⑩


⑤ IC802 ⑳


⑥ IC802 ㉒


⑦ IC802 ㉔




For schematic diagram

• Refer to page 4-51 for printed wiring board.



•SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	⇨		
PB	⇦		

PK-44 BOARD (3/5)

CAMERA REC/PB

⑧ IC903 ①



⑨ IC903 ④



⑩ IC901 ㉘

⑪ IC901 ㊲



⑫ IC902 ⑦

For schematic diagram
• Refer to page 4-51 for printed wiring board.



Note:	Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

For schematic diagram
• Refer to page 4-51 for printed wiring board.



PK-44 (REC/PB AMP, LCD DRIVE, TIMING GENERATOR, BACK-LIGHT, MODE SWITCH) PRINTED WIRING BOARD

— Ref. No. PK-44 Board; 2,000 Series —

PK-44 BOARD (SIDE A)



PK-44 BOARD (SIDE B)


LND702
LND712
LND713
LND704
LND705
R875
R876
R877
R855
R856
R857
R858
R853
R854
R867
C856
C850
C863
R868
D852
R860
R865
Q859
R863
Q855
R862
R861
Q858
R864
C865
C851
R866
R874
Q856
D853
C852
R873
C853
R872
D854
D711
D712
C854
C855
R871
Q857
R870
C857
R869
C858
D857
C859
D856
C860
D855
C861
D858
C862
D859
C863
D860
C864
D861
C865
D862
C866
D863
C867
D864
C868
D865
C869
D866
C870
D867
C871
D868
C872
D869
C873
D870
C874
D871
C875
D872
C876
D873
C877
D874
C878
D875
C879
D876
C880
D877
C881
D878
C882
D879
C883
D880
C884
D881
C885
D882
C886
D883
C887
D884
C888
D885
C889
D886
C890
D887
C891
D888
C892
D889
C893
D890
C894
D891
C895
D892
C896
D893
C897
D894
C898
D895
C899
D896
C900
D897
C901
D898
C902
D899
C903
D900
C904
D901
C905
D902
C906
D903
C907
D904
C908
D905
C909
D906
C910
D907
C911
D908
C912
D909
C913
D910
C914
D911
C915
D912
C916
D913
C917
D914
C918
D915
C919
D916
C920
D917
C921
D918
C922
D919
C923
D920
C924
D921
C925
D922
C926
D923
C927
D924
C928
D925
C929
D926
C930
D927
C931
D928
C932
D929
C933
D930
C934
D931
C935
D932
C936
D933
C937
D934
C938
D935
C939
D936
C940
D937
C941
D938
C942
D939
C943
D940
C944
D941
C945
D942
C946
D943
C947
D944
C948
D945
C949
D946
C950
D947
C951
D948
C952
D949
C953
D950
C954
D951
C955
D952
C956
D953
C957
D954
C958
D955
C959
D956
C960
D957
C961
D958
C962
D959
C963
D960
C964
D961
C965
D962
C966
D963
C967
D964
C968
D965
C969
D966
C970
D967
C971
D968
C972
D969
C973
D970
C974
D971
C975
D972
C976
D973
C977
D974
C978
D975
C979
D976
C980
D977
C981
D978
C982
D979
C983
D980
C984
D981
C985
D982
C986
D983
C987
D984
C988
D985
C989
D986
C990
D987
C991
D988
C992
D989
C993
D990
C994
D991
C995
D992
C996
D993
C997
D994
C998
D995
C999
D996
C9100
D997
C9101
D998
C9102
D999
C9103
D9100
C9104
D9101
C9105
D9102
C9106
D9103
C9107
D9104
C9108
D9105
C9109
D9106
C9110
D9107
C9111
D9108
C9112
D9109
C9113
D9110
C9114
D9111
C9115
D9112
C9116
D9113
C9117
D9114
C9118
D9115
C9119
D9116
C9120
D9117
C9121
D9118
C9122
D9119

DD-119 BOARD
CAMERA REC/PB

① IC301 ㊽

② IC301 ㊽





DD-119 (DC/DC CONVERTER) PRINTED WIRING BOARD

— Ref. No. DD-119 Board; 2,000 Series —



DD-119 BOARD

C302	E-1	C357	A-4	Q308	E-3	R332	E-1				
C303	E-1	C358	A-4	Q309	D-3	R333	E-1				
C304	D-1	C359	A-4	Q310	B-4	R334	E-2				
C305	D-1	C360	B-6	Q311	B-5	R335	E-2				
C306	D-1	C361	A-5	Q312	A-5	R336	E-1				
C307	D-1	C363	B-2	Q313	B-5	R337	D-1				
C308	E-1	C364	C-5	Q314	B-5	R340	D-1				
C309	D-1	C365	B-6	Q315	B-5	R341	D-1				
C310	E-1	C390	B-6	Q316	B-5	R342	D-1				
C311	D-2	C393	B-6	Q317	B-5	R343	E-2				
C312	E-1			Q318	C-6	R344	A-5				
C313	D-1	CN301	A-1	Q319	C-5	R346	E-2				
C314	E-1	CN302	E-6	Q320	B-5	R347	E-2				
C315	D-1	CN303	E-4	Q321	B-5	R348	E-2				
C316	E-2			Q322	C-6	R349	D-2				
C318	E-2	D304	B-4	Q323	C-5	R352	A-4				
C319	D-2	D305	B-4	Q324	B-5	R353	A-4				
C320	B-2	D306	B-4	Q325	B-5	R356	B-4				
C321	B-2	D307	B-5	Q326	B-5	R357	B-4				
C322	E-2	D308	E-2	Q327	B-5	R358	B-4				
C323	D-2			Q328	C-5	R360	B-5				
C324	B-2	F301	B-2	Q329	C-5	R361	B-5				
C325	E-2	F302	B-2	Q330	C-5	R362	B-5				
C326	E-2	F303	B-2	Q331	B-5	R363	B-5				
C327	E-2	F304	C-2	Q332	B-5	R364	B-5				
C328	D-2			Q333	B-6	R365	B-5				
C329	E-2	IC301	E-1	Q334	B-6	R366	B-5				
C330	E-2			Q335	B-6	R367	B-5				
C331	E-3	L301	B-3	Q336	A-5	R368	C-6				
C332	E-3	L302	B-3	Q337	B-6	R369	C-5				
C333	D-3	L303	A-3			R370	A-5				
C334	A-5	L304	B-3	R308	B-5	R371	B-5				
C335	D-5	L305	B-3	R309	E-1	R372	B-6				
C336	A-4	L306	A-5	R310	D-1	R373	C-5				
C337	B-4	L307	D-4	R312	D-1	R374	B-5				
C338	D-4	L308	A-4	R314	E-1	R375	B-5				
C339	D-3	L309	D-3	R315	E-1	R376	C-5				
C340	D-4	L310	E-4	R316	E-1	R377	C-5				
C342	B-4	L311	D-4	R317	E-1	R378	C-5				
C343	E-5	L312	E-4	R318	E-1	R379	C-5				
C344	B-5	L313	A-5	R319	E-1	R380	C-5				
C345	B-4	L314	A-4	R320	E-1	R381	C-5				
C346	B-5	L315	A-4	R321	D-1	R387	B-6				
C347	B-5	L316	A-3	R324	D-1	R388	B-6				
C348	A-5	L317	A-4	R325	D-1	R389	B-6				
C349	B-5			R326	D-1	R391	B-6				
C350	D-5	LF301	B-2	R327	E-1	R392	B-6				
C352	D-5			R328	E-1	R394	A-6				
C353	E-5	Q306	E-3	R330	E-2						
C354	B-6	Q307	E-4	R331	E-1	T301	B-4				

For printed wiring boards

- This board is six-layer print board. However, the patterns of layers two to five have not been included in the diagram.

There are few cases that the part printed on this diagram isn't mounted in this model.



RL-51 BOARD

C001	A-4	L001	B-4
C002	A-4		
C003	A-4	R001	A-4
C004	A-4	R002	A-4
C005	A-4	R003	B-3
C006	B-2	R004	B-3
C007	B-2	R005	B-2
C009	A-3	R006	B-2
C010	B-4	R007	B-2
C011	B-3	R008	B-1
C012	B-1	R009	B-1
C013	B-1	R010	A-1
C014	A-2	R011	B-1
C015	B-1	R012	B-4
C016	B-1	R013	B-2
		R014	B-1
CN001	A-3	R015	A-4
CN002	B-4	R016	B-1
		R017	B-1
D001	A-1	R018	B-4
D002	B-1	R019	B-4
D003	B-4	R020	B-2
IC001	A-4	S001	B-1
IC002	B-3		
IC003	B-1		

RL-51 (MIC AMP) PRINTED WIRING BOARD

— Ref. No. RL-51 Board; 2,000 Series —





For printed wiring boards

- This board is six-layer print board. However, the patterns of layers two to five have not been included in the diagram.
- Chip parts

Diode

There are few cases that the part printed on this diagram isn't mounted in this model.



SECTION 5
ADJUSTMENTS

5-1. CAMERA SECTION ADJUSTMENT

1-1. PREPARATIONS BEFORE ADJUSTMENT (CAMERA SECTION)

1-1-1. List of Service Tools

- Oscilloscope
- Regulated power supply
- Digital voltmeter
- Frequency counter
- AC power adapter

Ref. No.	Name		Parts Code	Usage
J-1	Filter for color temperature correction (C14)		J-6080-058-A	Auto white balance adjustment/check White balance adjustment/check
J-2	ND filter 1.0		J-6080-808-A	White balance check
	ND filter 0.3		J-6080-818-A	White balance check
J-3	Pattern box PTB-450		J-6082-200-A	
J-4	Color chart for pattern box		J-6020-250-A	
J-5	Siemens star chart		J-6080-875-A	For checking the flange back
J-6	Adjustment remote commander (RM-95 upgraded). (Note 2)		J-6082-053-B	
J-7	Clear chart for pattern box		J-6080-621-A	
J-8	CPC-9 jig (12P/18P, 0.5mm)		J-6082-393-B	For connecting the adjustment remote commander and the measuring instruments
J-9	Extension cable (10P, 0.8mm and 18P, 0.5mm)		J-6082-427-A	For extension between the FDD UNIT and PK-44 board (CN601, 602)
J-10	Extension cable (50P, 0.5mm)		J-6082-434-A	For extension between the DD-119 board (CN302) and the FC-67 board (CN603)
J-11	Alignment disk	TFD2-1(+)	8-967-990-01	For FDD dynamic inspection and LCD system adjustments
	(Two disks as pair)	TFD2-2(–)	8-967-990-11	
J-12	Cleaning disk (OR-D29WA)		8-960-009-39	For FDD head cleaning (Note 1)
	Cleaning disk		Available on market	
J-13	Personal computer with Windows95/98 installed			For checking the recorded picture
J-14	Power code		J-6082-223-A	For the battery end adjustment

Note 1: Usage and operating note
One or two seconds of momentary use of cleaning disk is sufficient such that FD is accessed momentarily by system control when main power is turn on. After cleaning, insert a FD for playback. When cleaning is insufficient, use a cleaning disk again.
Caution: Avoid using a cleaning disk excessively. Head can be broken.

Note 2: If the micro processor IC in the adjustment remote commander is not the new micro processor (UPD7503G-C56-12), The pages cannot be switched. In this case, replace with the new micro processor (8-759-148-35).



Fig. 5-1-1.

1-1-2. Preparations

Note 1: For details of how remove the cabinet and boards, refer to "2. DISASSEMBLY".

Note 2: When performing only the adjustments, the lens block and boards need not be disassembled.

1) Connect the equipment for adjustments according to Fig. 5-1-5.
2) Connect the Adjustment remote commander to PK-44 board CN802 via CPC-9 jig (J-6082-393-B). (See Fig. 5-1-3.)

Note 3: As disconnecting the FC-67 board CN602 means disconnecting the lithium 3V power supply (PK-44 board BH701), data such as date, time, user-set menus will be lost. After completing adjustments, reset these data. If the FC-67 board CN602 has been disconnected, the self-diagnosis data will be lost. Before disconnecting, note down the self-diagnosis data (data of page: 3, address: 2A to 3C). (Refer to "SELF-DIAGNOSIS FUNCTION" and "5-2.Service Mode" for the self-diagnosis data.)

Note 4: Setting the "Forced Camera Power ON" Mode
1) Select page: 0, address: 01, and set data: 01.
2) Select page: F, address: 10, set data: 01, and press the PAUSE button of the adjustment remote commander.
The above procedure will enable the camera power to be turned on. After completing adjustments, be sure to exit the "Forced Camera Power ON Mode".

Note 5: Exiting the "Forced Camera Power ON" Mode
1) Select page: 0, address: 01, and set data: 01.
2) Select page: F, address: 10, set data: 00, and press the PAUSE button of the adjustment remote commander.
3) Select page: 0, address: 01, and set data: 00.

1-1-3. Discharging of the flashlight power supply

The capacitor which is used as power supply of flashlight is charged with 200V to 300V voltage. Discharge this voltage before starting adjustments in order to protect service engineers from electric shock during adjustment.

Discharge procedure

1. Press the FLASH button (PK-44 board S707) and turn off the FLASH LED (PK-44 board D702).
2. Fabricate the discharging jig as shown in Fig. 5-1-4 locally by yourself. Connect the discharging jig to the positive (+) and negative (-) terminal of the flash voltage charge capacitor. Allow ten seconds to discharge the voltage.



Fig. 5-1-2.



Note: Don't use the 12 pin flexible board of CPC-9 jig. It causes damage to the unit.

Fig. 5-1-3.



Fig. 5-1-4.



Note 2: In changing data, wait for more than 5 seconds after the set was turned on, then change the data.
Note 3: Connect the GND terminal to Floppy disk drive unit frame when check the RF signal waveform.

Fig. 5-1-5.

1-1-4. Precaution

1. Setting the Switch

Unless otherwise specified, set the switches as follows and perform adjustments without loading cassette.

1. PLAY/STILL/MOVIE switch
   (PK-44board S708,712) ..... STILL
2. FOCUS switch ..... MANUAL
3. PROGRAM AE switch (PK-44board S706)
   ..... Auto (No mark indicated on LCD)
4. PICTURE EFFECT switch (PK-44board S703) .....OFF

2. Order of Adjustments

Basically carry out adjustments in the order given.

Color bar chart standard picture frame



External trigger : CN802 ⑧ pin (COM)



External trigger : CN802 ⑪ pin (LANC IN)

Fig. a VG signal waveform (CN802 ⑨ pin of PK-44 board)



Fig. b (LCD screen)

Adjust the camera zoom and direction to obtain the output waveform shown in Fig. a and the LCD screen shown in Fig. b.

Fig.5-1-6.

3. Subjects

1) Color bar chart (Standard picture frame)
   When performing adjustments using the color bar chart, adjust the picture frame as shown in Fig. 5-1-6. (Standard picture frame)
2) Clear chart (Standard picture frame)
   Remove the color bar chart from the pattern box and insert a clear chart in its place. (Do not perform zoom operations during this time.)
3) Flange back adjustment chart
   Make the chart shown in Fig. 5-1-7 using A0 size (1189mm × 841mm) black and white vellum paper.



Fig. 5-1-7.

Note: Use matte vellum paper bigger than A0, and make sure the edges of the black and white paper joined together are not rough.

1-2. INITIALIZATION OF F, E PAGE DATA

1. Initializing the F, E Page Data

Note: If the F, E page data is initialized, all adjustments must be performed again.

Adjusting page	F
Adjusting Address	00 to FF
Adjusting page	E
Adjusting Address	00 to FF

Initializing Method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 00, and set data: 2D.
3) Select page: 3, address: 01, set data: 2D, and press the PAUSE button of the adjustment remote commander.
4) Select page: 3, address: 00, and check that the data is "00".
5) Perform "Modification of F, E Page Data".

2. Modification of F, E Page Data

If the F, E PAGE data has been initialized, change the data of the "Fixed data-2" address shown in the following tables by manual input.

Modifying Method:

1) Before changing the data, select page: 0, address: 01, and set data: 01.
2) New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.
   Note: If copy the data built in the different model, the camcorder may not operate.
3) When changing the data, press the PAUSE button of the adjustment remote commander each time when setting new data to write the data in the non-volatile memory.
4) Check that the data of adjustment addresses is the initial value. If not, change the data to the initial value.

Processing after Completing Modification of F, E Page data

1) Select page: 3, address: 00, and set data: 29.
2) Select page: 3, address: 01, and set data: 29, and press the PAUSE button of the adjustment remote commander.
3) Perform all adjustments.

3. F Page Table

Note: Fixed data-1 : Initialized data. (Refer to "1. Initializing the F, E Page Data".)
Fixed data-2 : Modified data. (Refer to "2. Modification of F, E Page Data".)

Address	Initial value	Remark
00 to 0F		
10	00	Test mode
11		Fixed data-1
12		Fixed data-2
13		Fixed data-1
14		(Initialized data)
15		
16		
17		
18	80	Battery end adj.
19	88	
1A	AD	
1B	C2	
1C	CD	
1D		Fixed data-1
1E		(Initialized data)
1F		
20		Fixed data-2
21		
22		
23		
24		Fixed data-1
25		
26		Fixed data-2
27		
28		
29		
2A		Fixed data-1
2B		
2C		Fixed data-2
2D		
2E		
2F		Fixed data-1
30	BC	Bright adj. (LCD)
31	80	Color adj. (LCD)
32	B9	White balance adj. (LCD)
33	B7	
34	BE	Contrast adj. (LCD)
35	50	VCO adj. (LCD)
36	74	V-COM adj. (LCD)
37	C8	D range adj. (LCD)
38	7C	V-COM level adj. (LCD)
39		Fixed data-1
3A		(Initialized data)
3B		
3C		
3D		
3E		Fixed data-2
3F		Fixed data-1
40		
41		Fixed data-2
42		Fixed data-1
43		(Initialized data)
44		
45		
46		Fixed data-2
47		Fixed data-1
48		(Initialized data)
49		
4A		
4B		
4C		
4D		Fixed data-2
4E		Fixed data-1
4F		(Initialized data)
50		
51		Fixed data-2
52		Fixed data-1
53		(Initialized data)
54		

Address	Initial value	Remark
55		Fixed data-1
56		(Initialized data)
57		
58		
59		
5A		
5B		
5C		
5D		
5E		
5F		
60		
61		
62		
63		Fixed data-2
64		Fixed data-1
65		
66		Fixed data-2
67		Fixed data-1
68		
69		
6A		
6B		
6C		
6D		
6E		
6F		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		Fixed data-2
7A		Fixed data-1
7B		
7C		
7D		
7E		
7F		
80		
81		
82		
83		
84		
85		
86		
87		
88		
89		
8A		Fixed data-2
8B		Fixed data-1
8C		

Address	Initial value	Remark
8D		Fixed data-1
8E		(Initialized data)
8F		
90		
91		
92		
93		
94		
95		
96		
97		
98		
99		
9A		
9B		
9C		
9D		
9E		
9F		
A0		
A1		
A2		
A3		
A4		
A5		
A6		Fixed data-2
A7		
A8		Fixed data-1
A9		
AA		
AB		
AC		
AD		
AE		
AF		
B0		
B1		
B2		
B3		
B4		
B5		
B6	22	Flange back adj.
B7	19	
B8	99	
B9	20	
BA	5D	
BB	13	
BC		Fixed data-1
BD		
BE	00	Flange back adj.
BF	00	
C0	35	
C1	00	
C2	19	
C3	00	
C4	6E	

Address	Initial value	Remark
C5	02	Flange back adj.
C6		Fixed data-1
C7	78	HALL adj.
C8	80	
C9		Fixed data-1
CA	70	Light level adj.
CB	73	
CC	45	AWB standard data input
CD	39	
CE	06	
CF	60	
D0		Fixed data-1
D1		Fixed data-2
D2		
D3	B2	Auto white balance adj.
D4	46	
D5		Fixed data-2
D6		Fixed data-1
D7		(Initialized data)
D8		
D9		
DA		
DB		
DC		
DD		
DE		
DF		
E0		
E1		
E2		
E3		
E4		
E5		
E6		
E7		
E8		
E9		
EA		
EB		
EC		
ED		Fixed data-2
EE		Fixed data-1
EF		(Initialized data)
F0		
F1		
F2		
F3		
F4		
F5		Fixed data-2
F6		Fixed data-1
F7		(Initialized data)
F8		
F9		
FA		
FB		Fixed data-2
FC		Fixed data-1
FD		Fixed data-1
FE		(Initialized data)
FF		

Table. 5-1-1.

4. E Page table

Note: Fixed data-1 : Initialized data. (Refer to "1. Initializing the F, E Page Data".)
Fixed data-2 : Modified data. (Refer to "2. Modification of F, E Page Data".)

Address	Initial value	Remark
00		Fixed data-2
01		
02		
03		
04		Fixed data-1
05		(Initialized data)
06		
07		
08		
09		
0A		
0B		
0C		
0D		
0E		
0F		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
1A		
1B		
1C		
1D		
1E	14	HALL adj.
1F		Fixed data-1
20		(Initialized data)
21		
22		
23	F8	Color reproduction adj.
24	ED	
25	FF	
26	03	
27	F1	
28	3B	
29	27	
2A	08	
2B		Fixed data-1
2C		(Initialized data)

Address	Initial value	Remark
2D		Fixed data-1
2E		(Initialized data)
2F		
30		
31		
32		
33		
34		
35		
36		
37		
38		
39		
3A		
3B		
3C		
3D		
3E		
3F		
40		
41		
42	27	Strobe white balance adj.
43	77	
44		Fixed data-1
45		(Initialized data)
46		
47		
48		Fixed data-2
49		
4A		Fixed data-1
4B		(Initialized data)
4C		
4D		
4E		
4F		
50		
51		
52		
53		Fixed data-2
54		Fixed data-1
55		(Initialized data)
56		
57		
58		
59		
5A		
5B		
5C		
5D		
5E		
5F		
60		
61		
62		
63		
64		

Address	Initial value	Remark
65		Fixed data-1
66		(Initialized data)
67		
68		
69		
6A		
6B		
6C		
6D		
6E		
6F		
70		
71		
72		
73		
74		Fixed data-2
75		Fixed data-1
76		Fixed data-2
77		
78		Fixed data-1
79		(Initialized data)
7A		
7B		
7C		
7D		
7E		
7F		
80		
81	00	Strobe light level adj.
82		Fixed data-1
83		(Initialized data)
84		
85		
86		
87		
88		
89		
8A		
8B		
8C		
8D		
8E		
8F		
90		
91		
92		
93		
94		
95		
96		
97		
98		
99		
9A		Fixed data-2
9B		Fixed data-1
9C		

Address	Initial value	Remark
9D		Fixed data-1
9E		(Initialized data)
9F		
A0		
A1		
A2		
A3		
A4		
A5		
A6		
A7		
A8		
A9		
AA		
AB		
AC		
AD		
AE		
AF		
B0		
B1		
B2		
B3		
B4		
B5		
B6		
B7		
B8		
B9		
BA		
BB		
BC		
BD		
BE		
BF		
C0		
C1		
C2	00	CCD defect compensation
C3	00	
C4	00	
C5	00	
C6	00	
C7	00	
C8	00	
C9	00	
CA	00	
CB	00	
CC	00	
CD	00	
CE	00	
CF	00	
D0	00	
D1	00	
D2	00	
D3	00	
D4	00	

Address	Initial value	Remark
D5	00	CCD defect compensation
D6		Fixed data-1
D7		(Initialized data)
D8		
D9		
DA		
DB		
DC		
DD		
DE		
DF		
E0		
E1		
E2		
E3		
E4		
E5		
E6		
E7		
E8		
E9		
EA		
EB		
EC		
ED		
EE		
EF		
F0		
F1		
F2		
F3		
F4		
F5		
F6		
F7		
F8		
F9		
FA		
FB		
FC		
FD		
FE		
FF		

Table. 5-1-2.

1-3. CAMERA SYSTEM ADJUSTMENTS

1. Picture Frame Setting

Subject	Color bar chart standard picture frame (Approx. 90cm from the front of the lens)
Measurement Point	Pin ⑨ of CN802 (VG) of PK-44 board External trigger (Horizontal period) : Pin ⑧ of CN802 (COM) of PK-44 board External trigger (Vertical period) : Pin ⑪ of CN802 (LANC IN) of PK-44 board
Measuring Instrument	Oscilloscope and LCD screen
Specified Value	A=B, C=D, t=0 ± 0.1msec

Setting method:

1) Adjust the focus using the focus ring.
2) Adjust the zoom and the camera direction, and set to the specified position.
3) Mark the position of the picture frame on the LCD screen, and adjust the picture frame to this position in following adjustments using “Color bar chart standard picture frame”.

Check on the oscilloscope

1. Horizontal period



Fig. 5-1-8.

2. Vertical period



Fig. 5-1-9.

Check on the LCD screen



Fig. 5-1-10.

2. HALL Adjustment

For detecting the position of the lens iris, adjust the hall AMP gain and offset.

Subject	Not required	
Adjustment Page	F	E
Adjustment Address	C7, C8	1E

Note: Check that the data of page: 2, address: 02 is 00. If not, select page: 2, address: 01, set data: 00 and press the PAUSE button of the adjustment remote commander.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 2, address: 01, set data: 6D, and press the PAUSE button of the adjustment remote commander. (The HALL adjustment is performed and the adjustment data is stored in page: F, address: C7, C8 and page: E, address: 1E.)
3) Select page: 2, address: 02, and check that the data is "01".

Processing after Completing Adjustments

1) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander.
2) Select page: 0, address: 01, and set data: 00.

3. Flange Back Adjustment

The inner focus lens flange back adjustment is carried out automatically. In whichever case, the focus will be deviated during auto focusing/manual focusing.

Subject	Flange back adjustment chart (2.0 m from the front of the lens) (Luminance: 350 ± 50 lux)
Measurement Point	Check operation on LCD screen
Measuring Instrument	
Adjustment Page	F
Adjustment Address	B6 to BB, BE to C5

Adjusting method:

1) Check that at both the zoom lens TELE end and WIDE end, the center of the chart for the flange back adjustment and center of the exposure screen coincide.
2) Select page: 0, address: 01, and set data: 01.
3) Check that the data of page: F, address: B6 to BB, BE to C5 is the initial value (See table below).

Address	Data	Address	Data
B6	22	BF	00
B7	19	C0	35
B8	99	C1	00
B9	20	C2	19
BA	5D	C3	00
BB	13	C4	6E
BE	00	C5	02

4) Select page: 2, address: 02, and check that the data is "00".
5) Select page: 2, address: 01, set data: 13, and press the PAUSE button of the adjustment remote commander.
6) Select page: 2, address: 01, set data: 15, and press the PAUSE button of the adjustment remote commander.
   (The adjustment data will be automatically input to page: F, addresses: B6 to BB, BE to C5.)
7) Select page: 2, address: 02, and check that the data is "01".

Processing after Completing Adjustments

1) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander.
2) Select page: 0, address: 01, and set data: 00.

4. Flange Back Check

Subject	Siemens star (2.0 m from the front of the lens) (Luminance : approx. 200 lux)
Measurement Point	Check operation on LCD screen
Measuring Instrument	
Specified Value	Focused at the TELE end and WIDE end.

Checking method:

1) Place the siemens star 2.0m from the front of the lens.
2) Shoot the siemens star with the zoom TELE end.
3) Turn on the auto focus.
4) Check that the lens is focused.
5) Select page: 2, address: 21, and set data: 10.
6) While observe the LCD screen, change the zoom to the WIDE end and check that the lens is focused.

Processing after Completing Adjustments

1) Select page: 2, address: 21, and set data: 00.

5. Light Level Adjustment

Adjust the standard LV value.

Subject	Clear chart (Color bar standard picture frame)
Adjustment Page	F
Adjustment Address	CA, CB

Note: Check that the data of page: 2, address: 02 is 00. If not, select page: 2, address: 01, set data: 00 and press the PAUSE button of the adjustment remote commander.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 2, address: 10, and set data: 58.
3) Select page: 2, address: 01, set data: 0D, and press the PAUSE button of the adjustment remote commander.
   (When the adjustment data is take in, the data will be automatically input to page: F, address: CA and CB.)
4) Select page: 2, address: 02, and check that the data is “01”.

Processing after Completing Adjustments

1) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander.
2) Select page: 2, address: 10, and set data: 00.
3) Select page: 0, address: 01, and set data: 00.

6. Auto White Balance Standard Data Input

Subject	Clear chart (Color bar standard picture frame)
Adjustment Page	F
Adjustment Address	CC to CF

Note: Check that the data of page: 2, address: 02 is 00. If not, select page: 2, address: 01, set data: 00 and press the PAUSE button of the adjustment remote commander.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: E, address: 11, set data: 0A, and press the PAUSE button of the adjustment remote commander.
3) Select page: 2, address: 10, and set data: 58.
4) Select page: 2, address: 01, set data: 11, and press the PAUSE button.
5) Select page: 2, address: 01, set data: 0B, and press the PAUSE button.
   (When the standard data is take in, the data will be automatically input to page: F, address: CC to CF.)
6) Select page: 2, address: 02, and check that the data is "01".

Processing after Completing Adjustments

1) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjustment remote commander.
2) Select page: E, address: 11, set data: 18, and press the PAUSE button.
3) Select page: 2, address: 10, and set data: 00.
4) Select page: 0, address: 01, and set data: 00.

7. Auto White Balance Adjustment

Adjust to the proper auto white balance output data.
If it is not correct, auto white balance and color reproducibility will be poor.

Subject	Clear chart (Color bar standard picture frame)
Filter	Filter C14 for color temperature correction
Measurement Point	DDS display of LCD screen (Note 2)
Measuring Instrument	
Adjustment Page	F
Adjustment Address	D3, D4
Specified Value	R ratio: 2B40 to 2BC0 B ratio: 5E40 to 5EC0

Note 1: Perform "Auto White Balance Standard Data Input" before this adjustment.

Note 2: The right four digits of the display data is the object data.



Adjusting method:

1) Place the C14 filter for color temperature correction on the lens.
2) Select page: 0, address: 01, and set data: 01.
3) Select page: E, address: 11, set data: 0A, and press the PAUSE button of the adjustment remote commander.
4) Select page: F, address: 11, set data: 02, and press the PAUSE button.
5) Select page: 2, address: 10, and set data: 58.
6) Select page: 2, address: 01, and set data: 3F, and press the PAUSE button.
7) Select page: 0, address: 03, and set data: 04.
8) Select page: F, address: D3, change the data and adjust the average value of the DDS display data (Note 2) to the R ratio specified value.
9) Press the PAUSE button.
10) Select page: 0, address: 03, and set data: 05.
11) Select page: F, address: D4, change the data and adjust the average value of the DDS display data (Note 2) to the B ratio specified value.
12) Press the PAUSE button.

Processing after Completing Adjustments

1) Select page: E, address: 11, set data: 18, and press the PAUSE button of the adjustment remote commander.
2) Select page: F, address: 11, set data: 00, and press the PAUSE button.
3) Select page: 0, address: 01, and set data: 00.
4) Select page: 0, address: 03, and set data: 00.
5) Select page: 2, address: 01, set data: 00, and press the PAUSE button.
6) Select page: 2, address: 10, and set data: 00.

8. Color Reproduction Adjustment

Adjust the color separation matrix coefficient so that proper color reproduction is produced.

Subject	Color bar chart standard picture frame
Measurement Point	CHX: Pin ① of CN802 of PK-44 board (PANEL B-Y) CHY: Pin ③ of CN802 of PK-44 board (PANEL R-Y)
Measuring Instrument	Oscilloscope (X-Y mode)
Adjustment Page	E
Adjustment Address	23, 24, 25, 26, 27, 28, 29. 2A
Specified Value	All color luminance points should settle within each color reproduction point.

Note: This adjustment should be carried out upon completion of "6. Auto White Balance Standard Data Input".

Preparations before adjustments

1) Set to the PLAY mode.
2) Playback the color bar signal (MVC-001C.JPG) of the alignment disk (TFD2-1(+) or TFD2-2(–)).
3) Select page: 0, address: 01, and set data: 01.
4) Select page: 3, address: 02, and set data: 01.
5) Select page: F, address: E0, set data: 40, and press the PAUSE button of the adjustment remote commander.
6) Adjust the X POSITION and Y POSITION of the oscilloscope, and adjust the black luminance point to the center of the CRT screen.
7) Adjust the Xch GAIN and Ych GAIN of the oscilloscope, and settle each color luminance point in each color reproduction frame (frame of the thin line).
8) Repeat steps 6) to 7) until each color luminance point settled in each color reproduction frame (frame of the thin line).
9) Set to the camera (STILL) mode.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 2, address: 10, and set data: 59.
3) Select page: 2, address: 01, set data: 0F, and press the PAUSE button.
4) Adjust the X POSITION and Y POSITION of the oscilloscope, and adjust the black luminance point to the center of the CRT screen.
5) Change the data of page: E, address: 23, 24, 27 and 28, and settle the yellow and blue luminance points in each color reproduction frame (frame of the thick line).
   Note 2: Be sure to press the PAUSE button of the adjustment remote commander before changing the addresses. If not, the new data will not be written to the memory.
6) Adjust the X POSITION and Y POSITION of the oscilloscope, and adjust the black luminance point to the center of the CRT screen.
7) Change the data of page: E, address: 25, 26, 29 and 2A, and settle the red, magenta,cyan and green luminance points in each color reproduction frame (frame of the thick line).
   Note 2: Be sure to press the PAUSE button of the adjustment remote commander before changing the addresses. If not, the new data will not be written to the memory.
8) Repeat steps 4) to 7) until all color luminance point settled within each color reproduction frame (frame of the thick line).

Processing after Completing Adjustments

1) Select page: F, address: E0, set data: 1B, and press the PAUSE button .
2) Select page: 0, address: 01, set data: 00.
3) Select page: 2, address: 01, and set data: 00, and press the PAUSE button .
4) Select page: 2, address: 10, set data: 00.
5) Select page: 3, address: 02, and set data: 00.



Fig. 5-1-11.

9. White Balance Check

Subject	Clear chart (Color bar standard picture frame)
Filter	ND filter 1.0 and 0.3
Measurement Point	Display data of page: 1
Measuring Instrument	Adjustment remote commander
Specified Value	R-Y data: FC to FF or 00 to 04 (Note1) B-Y data: FC to FF or 00 to 04 (Note1) Light level data: Without ND filter: 0E10 or more (Note2) With ND filter 1.3: 0D00 or less (Note2)

Note 1: Displayed data of page 1 of the adjustment remote commander.

1 : XX : XX
- XX: R-Y data
- XX: B-Y data

Note 2: Displayed data of page 1 of the adjustment remote commander.

1 : XX : XX
- XX: Light level data

Checking method:

1) Check that the lens is not covered with the ND filter.
2) Select page: 0, address: 01, and set data: 01.
3) Select page: E, address: 11, set data: 15, and press the PAUSE button of the adjustment remote commander.
4) Select page: 0, address: 03, and set data: 02.
5) Select page: 2, address: 10, and set data: 58.
6) Select page: 2, address: 56, and set data: 56.
7) Select page: 2, address: 01, set data: 0F, and press the PAUSE button.
8) Select page: 1, and check that the R-Y data satisfies the specified value and the B-Y data satisfies the specified value. (Note1)
9) Select page: 0, address: 03, and set data: 06.
10) Select page: 1, and check that the light level data satisfies the specified value. (Note2)
11) Place the ND 1.3 filter on the lens.
12) Select page: 1, and check that the light level data satisfies the specified value. (Note2)

Processing after Completing Adjustments

1) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander.
2) Select page: 2, address: 10, and set data: 00.
3) Select page: 2, address: 56, and set data: 00.
4) Select page: E, address: 11, set data: 18, and press the PAUSE button.
5) Select page: 0, address: 01, and set data: 00.
6) Select page: 0, address: 03, and set data: 00.

10. Strobe Light Level Adjustment

Adjust the minimum gain when the strobe light flashes.

Subject	Clear chart (Color bar standard picture frame)
Measurement Point	Display data of page : 1
Measuring Instrument	Adjustment remote commander
Adjustment Page	E
Adjustment Address	81
Specified Value	01E7 to 0267

Note: Displayed data of page 1 of the adjustment remote commander.

1 :XX:XX
- XX: Object data

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: E, address: 70, set data: 03, and press the PAUSE button of the adjustment remote commander.
3) Select page: E, address: 71, set data: 00, and press the PAUSE button.
4) Select page: 2, address: 10, and set data: 58.
5) Select page: 2, address: 01, set data: 9D, and press the PAUSE button.
6) Select page: 1, and read the display data (Note). If the display data lies within the “0207” to “0247” range, perform “Processing after Completing Adjustments”.
7) Select page: E, address: 81, change the data, and press the PAUSE button.
8) Select page: 1, and check that the display data lies within the “0207” to “0247” range. If not, repeat steps 7) to 8).
9) Select page: 2, address: 01, set data: 00, and press the PAUSE button.
10) Select page: 2, address: 01, set data: 9D, and press the PAUSE button.
11) Select page: 1, and check that the display data satisfies the specified value.

Processing after Completing Adjustments

1) Select page: E, address: 70, set data: 00, and press the PAUSE button of the adjustment remote commander.
2) Select page: E, address: 71, set data: 00, and press the PAUSE button.
3) Select page: 0, address: 01, and set data: 00.
4) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander.
5) Select page: 2, address: 10, and set data: 00.

11. Strobe White Balance Adjustment

Adjust the white balance when the strobe light flashes.

Subject	A plate which reflection rate is 18% (1.0m from the front of the lens)
Measurement Point	Display data of page : 1
Measuring Instrument	Adjustment remote commander
Adjustment Page	E
Adjustment Address	42, 43

Note 1: Perform this adjustment in the dark room or use a dark box.
Note 2: Any light other than the strobe light should not light up the plate.
Note 3: Displayed data of page 1 of the adjustment remote commander.



Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: E, address: 11, set data: 15, and press the PAUSE button of the adjustment remote commander.
3) Select page: 2, address: 10, and set data: 58.
4) Select page: 2, address: 56, and set data: 89.
5) Select page: 2, address: 90, and set data: 00.
6) Select page: 2, address: 91, and set data: 00.
7) Select page: 2, address: 92, and set data: 00.
8) Select page: 2, address: 93, and set data: 80.
9) Select page: 2, address: 01, set data: 79, and press the PAUSE button.
10) Select page: 2, address: 01, set data: 67, and press the PAUSE button.
11) Check the flashing of the strobe light.
12) Select page: 0, address: 03, and set data: 05.
13) Select page: 1, and read the strobe R data and strobe B data.
14) Select page: E, address: 42, set the strobe R data, and press the PAUSE button.
15) Select page: E, address: 43, set the strobe B data, and press the PAUSE button.

Processing after Completing Adjustments

1) Select page: E, address: 11, set data: 18, and press the PAUSE button of the adjustment remote commander.
2) Select page: 0, address: 01, and set data: 00.
3) Select page: 0, address: 03, and set data: 00.
4) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander.
5) Select page: 2, address: 10, and set data: 00.
6) Select page: 2, address: 56, and set data: 00.
7) Select page: 2, address: 90, and set data: 00.
8) Select page: 2, address: 91, and set data: 00.
9) Select page: 2, address: 92, and set data: 00.
10) Select page: 2, address: 93, and set data: 00.

12. Strobe Light Level and White Balance Check

Check the light level regulation and the white balance when the strobe light flashes.

Subject	A plate which reflection rate is 18% (1.0m from the front of the lens)
Measurement Point	Display data of page : 1
Measuring Instrument	Adjustment remote commander
Specified Value	Y level data : 70 to 95 (Note 3) R-Y data : FA to FF or 00 to 06 (Note 4) B-Y data : FA to FF or 00 to 06 (Note 4)

Note 1: Perform this adjustment in the dark room or use a dark box.
Note 2: Any light other than the strobe light should not light up the plate.
Note 3: Display data of page 1 of the adjustment remote commander.



Note 4: Display data of page 1 of the adjustment remote commander.



Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: E, address: 11, set data: 15, and press the PAUSE button of the adjustment remote commander.
3) Select page: 2, address: 10, and set data: 58.
4) Select page: 2, address: 56, and set data: 89.
5) Select page: 2, address: 90, and set data: 00.
6) Select page: 2, address: 91, and set data: 00.
7) Select page: 2, address: 92, and set data: 00.
8) Select page: 2, address: 93, and set data: 80.
9) Select page: 2, address: 01, set data: 79, and press the PAUSE button.
10) Select page: 2, address: 01, set data: 67, and press the PAUSE button.
11) Check the flashing of the strobe light.
12) Select page: 0, address: 03, and set data: 01.
13) Select page: 1, and check that the Y level data satisfies the specified value. (Note 3).
14) Select page: 0, address: 03, and set data: 04.
15) Select page: 1, and check that the R-Y data satisfies the specified value and the B-Y data satisfies the specified value. (Note 4)

Processing after Completing Adjustments

1) Select page: E, address: 11, set data: 18, and press the PAUSE button of the adjustment remote commander.
2) Select page: 0, address: 01, and set data: 00.
3) Select page: 0, address: 03, and set data: 00.
4) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander.
5) Select page: 2, address: 10, and set data: 00.
6) Select page: 2, address: 56, and set data: 00.
7) Select page: 2, address: 90, and set data: 00.
8) Select page: 2, address: 91, and set data: 00.
9) Select page: 2, address: 92, and set data: 00.
10) Select page: 2, address: 93, and set data: 00.

13. CCD Defect Compensation

Subject	Clear chart (40 cm from the front of the lens)
Adjustment Page	E
Adjustment Address	C2 to D5

Note 1: Check that there are no dust, no dirt and no reflection on the clear chart.
Note 2: Any subject other than the clear chart should not be in the screen.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Check that the data of page: E, address: C2 to D5 is “00”. If not, change the data to “00”, and press the PAUSE button.
3) Turn the power of the unit OFF and then ON.
4) Wait until the camera picture appear on the LCD screen.
5) Select page: 0, address: 01, and set data: 01.
6) Select page: E, address: 11, set data: 56, and press the PAUSE button of the adjustment remote commander.
7) Select page: E, address: C0, set data: 14, and press the PAUSE button.
8) Select page: 2, address: 01, set data: 8D, and press the PAUSE button.
   (When the compensation data is take in, the data will be automatically input to page: F, address: C2 to D5.)
9) Select page: 2, address: 02, and check that the data is “01”.

Processing after Completing Adjustments

1) Select page: E, address: 11, set data: 18, and press the PAUSE button.
2) Select page: 0, address: 01, and set data: 00.
3) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjustment remote commander.

14. CCD Defect Compensation Check

Subject	Clear chart (40 cm from the front of the lens)
Measurement Point	Display data of page : 3, address : FF
Measuring Instrument	Adjustment remote commander
Specified Value	00

Note 1: Check that there are no dust, no dirt and no reflection on the clear chart.
Note 2: Any subject other than the clear chart should not be in the screen.
Note 3: This adjustment should be carried out upon completion of “13. CCD Defect Compensation”.

Adjusting method:

1) Turn the power of the unit OFF and then ON.
2) Wait until the camera picture appear on the LCD screen.
3) Select page: 0, address: 01, and set data: 01.
4) Select page: E, address: 11, set data: 56, and press the PAUSE button of the adjustment remote commander.
5) Select page: 3, address: FA, and set data: 45.
6) Select page: 2, address: 01, set data: 89, and press the PAUSE button.
7) Select page: 3, address: 4C, and check that the data changed to “01”.
8) Select page: 3, address: FF, and check that the data is “00”.
   Note: If the data of page: 3, address: FF is “01” to “0F”, the CCD defect compensation is defective.

Processing after Completing Adjustments

1) Select page: E, address: 11, set data: 18, and press the PAUSE button.
2) Select page: 0, address: 01, and set data: 00.
3) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjustment remote commander.

1-4. LCD SYSTEM ADJUSTMENT

Note 1: The back light (fluorescent tube) is driven by a high voltage AC power supply. Therefore, do not touch the back light holder to avoid electrical shock.

Note 2: When replacing the LCD unit, be careful to prevent damages caused by static electricity.

Note 3: Set the LCD BRIGHT to the center.

[Adjusting connector]

Most of the measuring points for adjusting the LCD system are concentrated in CN802 of the PK-44 board.
Connect the Measuring Instruments via the CPC-9 jig (J-6082-393-B).
The following table shows the Pin No. and signal name of CN802.

Pin No.	Signal Name	Pin No.	Signal Name
1	PANEL B-Y	10	UNREG
2	PANEL Y	11	LANC IN
3	PANEL R-Y	12	LANC OUT
4	REG GND	13	XPOWER SW
5	JIG XHD	14	MAKER RECOG
6	JIG XVD	15	INDEX
7	HSY	16	TRACK 00
8	COM	17	JIG VCO
9	VG	18	FDD RF

Table 5-1-9.



Note: Don't use the 12 pin flexible board of CPC-9 jig. It causes damage to the unit.

Fig. 5-1-12.

[Alignment disk]

Use the alignment disks (two disks as pair) shown in below.
Disk-1: TFD2-1(+) (Parts code; 8-967-990-01)
Disk-2: TFD2-2(-) (Parts code; 8-967-990-11)

Contents of alignment disk
TFD2-1(+): (Common signal) + (+17.5 μm alignment)
TFD2-2(-): (Common signal) + (–17.5 μm alignment)

Common signal

File name	Signal
MVC-001C.JPG	Color bars
MVC-002M.JPG	Monoscope
MVC-003V.JPG	V-COM adjustment signal
MVC-004W.JPG	100% white
MVC-005H.JPG	50% white
MVC-006T.JPG	Stair-step signal of 10 step
MVC-007R.JPG	Red single color
MVC-008G.JPG	Green single color
MVC-009B.JPG	Blue single color
MVC-010D.JPG	Camera color bars
MVC-011N.JPG	Camera monoscope

1. LCD Initial Data Input

Mode	Playback
Signal	Arbitrary
Adjustment Page	F
Adjustment Address	30 to 38, 3B to 46, 4A, E0

Adjusting method:

1) Select page: 0, address:01, and set data: 01.
2) Select page: F, and input the data in the following table.
   Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjustment remote commander each time to set the data.

Address	Data	Remark
30	BC	Bright adjustment
31	80	Color adjustment
32	B9	White balance adjustment
33	B7	White balance adjustment
34	BE	Contrast adjustment
35	50	VCO adjustment
36	74	V-COM adjustment
37	C8	D range adjustment
38	7C	V-COM level adjustment
3B	72	Fixed value
3C	22	Fixed value
3D	11	Fixed value
3E	2E	Fixed value
3F	00	Fixed value
40	11	Fixed value
41	15	Fixed value
42	00	Fixed value
43	00	Fixed value
44	44	Fixed value
45	48	Fixed value
46	33	Fixed value
4A	9A	Fixed value
E0	1B	Fixed value

Processing after Completing Adjustment

1) Select page: 3, address: 00, and set data: 29.
2) Select page: 3, address: 01, and set data: 29, and press the PAUSE button of the adjustment remote commander.

2. VCO Adjustment (PK-44 board)

Set the VCO free-run frequency. If deviated, the LCD screen will be blurred.

Mode	Playback
Signal	arbitrary
Measurement Point	Pin ⑦ of CN802 (HSY)
Measuring Instrument	Frequency counter
Adjustment Page	F
Adjustment Address	35
Specified Value	f = 13200 ± 30Hz

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: 3, address: 19, and set data: 20.
4) Select page: F, address: 35, change the data and set the frequency (f) to the specified value.
5) Press the PAUSE button of the adjustment remote commander.
6) Select page: 3, address: 02, and set data: 00.
7) Select page: 3, address: 19, and set data: 00.
8) Select page: 0, address: 01, and set data: 00.

3. D range Adjustment (PK-44 board)

Set the D range of the LCD driver to the specified value. If deviated, the LCD screen will become blackish or saturated (whitish).

Mode	Playback
Signa	Alignment disk (TFD2-1(+) or TFD2-2(–)): Stair step signal of 10 steps (MVC-006T.JPG)
Measurement Point	Pin ⑨ of CN802 (VG) External trigger: Pin ⑧ of CN802 (COM)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	37
Specified Value	A = 3.62 ± 0.05V

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: F, address: 37, change the data and set the voltage (A) between the reversed waveform pedestal and non-reversed waveform pedestal to the specified value.
4) Press the PAUSE button of the adjustment remote commander.
5) Select page: 3, address: 02, and set data: 00.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-13.

4. Bright Adjustment (PK-44 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	Playback
Signal	Alignment disk (TFD2-1(+) or TFD2-2(–)): Stair step signal of 10 steps (MVC-006T.JPG)
Measurement Point	Pin ⑨ of CN802 (VG) External trigger: Pin ⑧ of CN802 (COM)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	30
Specified Value	A = 2.05 ± 0.05V

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: 3, address: 19, and set data: 08.
4) Select page: F, address: 30, change the data and set the voltage (A) between the pedestal and white level to the specified value.
5) Press the PAUSE button of the adjustment remote commander.
6) Select page: 3, address: 02, and set data: 00.
7) Select page: 3, address: 19, and set data: 00.
8) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-14.

5. Contrast Adjustment (PK-44 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	Playback
Signal	Alignment disk (TFD2-1(+) or TFD2-2(–)): Stair step signal of 10 steps (MVC-006T.JPG)
Measurement Point	Pin ⑨ of CN802 (VG) External trigger: Pin ⑧ of CN802 (COM)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	34
Specified Value	A = 3.52 ± 0.07V

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: F, address: 34, change the data and set the voltage (A) between the 0 IRE (pedestal) and 100 IRE to the specified value.
4) Press the PAUSE button of the adjustment remote commander.
5) Select page: 3, address: 02, and set data: 00.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-15.

6. Color Adjustment (PK-44 board)

Set the color saturation to the standard value. If deviated, the color will be to dark or light.

Mode	Playback
Signal	Alignment disk (TFD2-1(+) or TFD2-2(–)): Color bar signal (MVC-001C.JPG)
Measurement Point	Pin ⑨ of CN802 (VG) External trigger: Pin ⑧ of CN802 (COM)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	31
Specified Value	A = 0.00 ± 0.05V

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: F, address: 31, change the data and set the voltage (A) between the white and green to the specified value.
4) Press the PAUSE button of the adjustment remote commander.
5) Select page: 3, address: 02, and set data: 00.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-16.

7. V-COM Level Adjustment (PK-44 board)

Set the common electrode drive signal level of LCD to the specified value.

Mode	Playback
Signal	No signal
Measurement Point	Pin ⑧ of CN802 (COM)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	38
Specified Value	A = 6.50 ± 0.05V

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: F, address: 38, change the data and set the V-COM signal level (A) to the specified value.
4) Press the PAUSE button of the adjustment remote commander.
5) Select page: 3, address: 02, and set data: 00.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-17.

8. V-COM Adjustment (PK-44 board)

Set the DC bias of the common electrode drive signal of LCD to the specified value.
If deviated, the LCD display will move, producing flicker and conspicuous vertical lines.

Mode	Playback
Signal	No signal
Measurement Point	Check on LCD screen
Measuring Instrument	
Adjustment Page	F
Adjustment Address	36
Specified Value	The brightness difference between the section A and section B is minimum.

Note 1: Perform "Bright Adjustment" and "Contrast Adjustment" before this adjustment.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: 3, address: 18, and set data: 01.
4) Select page: 3, address: 19, and set data: 10.
5) Select page: F, address: 36, change the data so that the brightness of the section A and that of the section B is equal.
6) Press the PAUSE button of the adjustment remote commander.
7) Select page: 3, address: 02, and set data: 00.
8) Select page: 3, address: 18, and set data: 00.
9) Select page: 3, address: 19, and set data: 00.
10) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-18.

9. White Balance Adjustment (PK-44 board)

Correct the white balance.
If deviated, the LCD screen color cannot be reproduced.

Mode	Playback
Signal	No signal
Measurement Point	Check on LCD screen
Measuring Instrument	
Adjustment Page	F
Adjustment Address	32, 33
Specified Value	The LCD screen should not be colored.

Note 1: Check the white balance only when replacing the following parts. If necessary, adjust them.
1. LCD panel
2. Light induction plate
3. IC802

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 02, and set data: 01.
3) Select page: 3, address: 18, and set data: 01.
4) Select page: 3, address: 19, and set data: 00.
5) Select page: F, address: 32 and 33, set the data to the initial value.
   Note: Press the PAUSE button of the adjustment remote commander each time to set the data.

Address	32	33
Data	B9	B7

6) Check that the LCD screen is not colored. If colored, change the data of page: F, address: 32 and 33 so that the LCD screen is not colored.
   Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjustment remote commander each time to set the data.
7) Select page: 3, address: 02, and set data: 00.
8) Select page: 3, address: 18, and set data: 00.
9) Select page: 0, address: 01, and set data: 00.

1-5. SYSTEM CONTROL SYSTEM ADJUSTMENT

1. Battery End Adjustment (FC-67 board)

Set the battery end voltage.
If the voltage is incorrect, the life of the battery will shorten.
The image at the battery end will also be rough.

Mode	Camera
Subject	All black (Cover the lens with a black cap)
Measurement Point	LCD display of the adjustment remote commander
Measuring Instrument	
Adjustment Page	F
Adjustment Address	18 to 1C

Switch setting

1) AUTO FOCUS / MANUAL ..... MANUAL

Connection:

1) Connect the regulated power supply to the battery terminal and connect the digital voltmeter to CN301 of DD-119 board as shown in Fig. 5-1-19.

Adjusting method:

1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display is 6.1 ± 0.1Vdc.
2) Turn on the HOLD switch of the adjustment remote commander.
3) Turn on the power.
4) Select page: 0, address: 01, and set data: 01.
5) Decrease the output voltage of the regulated power supply so that the digital voltmeter display is 5.80 ± 0.01Vdc.
6) Select page: 3, address: 0D, read the data, and this data is named Dref.
7) Select page: F, address: 18, set data: Dref, and then press the PAUSE button of the adjustment remote commander.
8) Convert Dref to decimal notation, and obtain Dref'. (Refer to Table 5-2-1. "Hexadecimal-decimal conversion table" of "5-2.Service mode")
9) Calculate D_{19}', D_{1A}', D_{1B}' and D_{1C}' using following equations (decimal calculation), convert it to a hexadecimal number, and input each adjustment address.
   Address: 19 D_{19}' = Dref'+8
   Address: 1A D_{1A}' = Dref'+23
   Address: 1B D_{1B}' = Dref'+44
   Address: 1C D_{1C}' = Dref'+55
   Note 3: After setting each data, be sure to press the PAUSE button.
10) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-19.

2. Alignment check (FDD UNIT)

Confirm that the FDD alignment is within the specifications.
If deviated, reading and writing data from and to the floppy disk become impossible. Or compatibility of the floppy disk with other machines can be lost.

Mode	Playback
Signal	Alignment disks (TFD2-1(+) and TFD2-2(–)): Arbitrary signal
Measurement Point	Check on LCD screen
Measuring Instrument	
Specified Value	The playback pictures should be normal.

Adjusting method:

1) Disconnect the adjustment commander.
2) Insert the alignment disk TFD2-1(+) (+17.5 μm).
3) Playback arbitrary signal and check that the playback picture is normal.
4) Insert the alignment disk TFD2-2(–) (–17.5 μm).
5) Playback arbitrary signal and check that the playback picture is normal.

5-2. SERVICE MODE

2-1. ADJUSTMENT REMOTE COMMANDER

The adjustment remote commander is used for changing the calculation coefficient in signal processing, EVR data, etc. The adjustment remote commander performs bi-directional communication with the unit using the remote commander signal line (LANC). The resultant data of this bi-directional communication is written in the non-volatile memory.

1. Using the adjustment remote commander

1) Connect the adjustment remote commander to CN802 of PK-44 board via CPC-9 jig (J-6082-393-B).
2) Set the HOLD switch of the adjustment remote commander to "HOLD" (SERVICE position). If it has been properly connected, the LCD on the adjustment remote commander will display as shown in Fig. 5-2-1.

Fig. 5-2-1.

3) Operate the adjustment remote commander as follows.
   - Changing the page
     The page increases when the EDIT SEARCH+ button is pressed, and decreases when the EDIT SEARCH– button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal notation	0 1 2 3 4 5 6 7 8 9 A B C D E F
LCD Display	0 1 2 3 4 5 6 7 8 9 A b c d E F
Decimal notation conversion value	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

   - Changing the address
     The address increases when the FF (►►) button is pressed, and decreases when the REW (◄◄) button is pressed. There are altogether 256 addresses, from 00 to FF.
   - Changing the data (Data setting)
     The data increases when the PLAY (►) button is pressed, and decreases when the STOP (■) button is pressed. There are altogether 256 data, from 00 to FF.
   - Writing the adjustment data
     The PAUSE button must be pressed to write the adjustment data (E, F page) in the nonvolatile memory. (The new adjusting data will not be recorded in the nonvolatile memory if this step is not performed.)
4) After completing all adjustments, turn off the main power supply once.

2. Precautions upon using the adjustment remote commander

Mishandling of the adjustment remote commander may erase the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment.

2-2. DATA PROCESS

The calculation of the DDS display and the adjustment remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Indicates the hexadecimal-decimal conversion table.

Hexadecimal-decimal Conversion Table

Lower digit of hexadecimal / Upper digit of hexadecimal	0	1	2	3	4	5	6	7	8	9	A (A)	B (b)	C (C)	D (d)	E (E)	F (F)
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
4	64	65	66	67	68	69	70	71	72	73	74	77	76	77	78	79
5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
A (A)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
① B (b)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
C (C)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
D (d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
E (E)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
F (F)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

② (column header)

Note: The characters shown in the parenthesis ( ) shown the display on the adjustment remote commander.

(Example) If the DDS display or the adjustment remote commander shows BD (bd);
Because the upper digit of the adjustment number is B (b), and the lower digit is D (d), the meeting point "189" of ① and ② in the above table is the corresponding decimal number.

Table. 5-2-1.

2-3. SERVICE MODE

1. Setting the Test Mode

Page F	Address 10

Data	Function
00	Normal
01	Forced camera power ON
02	Forced Player power ON

- Before setting the data , select page: 0, address: 01, and set data: 01.
- For page F, the data set is recorded in the non-volatile memory by pressing the PAUSE button of the adjustment remote commander. In this case, take note that the test mode will not be exited even when the main power is turned off.
- After completing adjustments/repairs, be sure to return the data of this address to 00, and press the PAUSE button of the adjustment remote commander.
  Select page: 0, address: 01, and set data: 00.

2. Bit value discrimination

Bit values must be discriminated using the display data of the adjustment remote commander for following items. Use the table below to discriminate if the bit value is “1” or “0”.



	Display on the adjustment remote commander	Bit values			
		bit3 or bit7	bit2 or bit6	bit1 or bit5	bit0 or bit4
	0	0	0	0	0
	1	0	0	0	1
	2	0	0	1	0
	3	0	0	1	1
	4	0	1	0	0
	5	0	1	0	1
	6	0	1	1	0
	7	0	1	1	1
Ⓐ	8	1	0	0	0
	9	1	0	0	1
	A (R)	1	0	1	0
	B (b)	1	0	1	1
	C (c)	1	1	0	0
	D (d)	1	1	0	1
Ⓑ	E (E)	1	1	1	0
	F (F)	1	1	1	1

Example: If “8E” is displayed on the adjustment remote commander, the bit values for bit7 to bit4 are shown in the Ⓐ column, and the bit values for bit3 to bit0 are shown in the Ⓑ column.

3. Switch check (1)

Page 3	Address 23

Bit	Function	When bit value=1	When bit value=0
0	POWER SW (PK-44 board S702)	OFF	ON
1	XCAM/PB SW (PK-44 board S708)	ON	OFF
2	SHUTTER SW (RL-51 board S001)	OFF	ON
3	SHUTTR AE LOCK SW (RL-51 board S001)	OFF	ON
4	DISK IN SW (FDD UNIT)	DISK IN	NO DISK
5			
6			
7	MOVIE/XSTILL SW (PK-44 board S712)	ON	OFF

Using method:

1) Select page:3, address: 23.
2) By discriminating the bit value of display data, the state of the switches can be discriminated.

4. Switch check (2)

Page 3	Address 13 to 17

Using method:

1) Select page:3, address: 13 to 17.
2) By discriminating the display data, the pressed key can be discriminated.

Address	Data						
	Adout“00”	Adout“29”	Adout“54”	Adout“82”	Adout“A6”	Adout“E5”	Adout“FF”
13 (KEY AD0) (IC702 ㉛)	VOLUME + (PK-44 board) (S705)	VOLUME - (PK-44 board) (S709)	BRIGHT + (PK-44 board) (S716)	BRIGHT - (PK-44 board) (S715)			No key input
14 (KEY AD1) (IC702 ㉜)	CONTROL DOWN (PK-44 board) (S701)	CONTROL UP (PK-44 board) (S701)	DISPLAY (PK-44 board) (S704)			BACK LIGHT OFF (PK-44 board) (S710)	BACK LIGHT ON (PK-44 board) (S710)
15 (KEY AD2) (IC702 ㉝)	CONTROL RIGHT (PK-44 board) (S701)	CONTROL LEFT (PK-44 board) (S701)	CONTROL SET (PK-44 board) (S701)	FLASH (PK-44 board) (S707)			No key input
16 (KEY AD3) (IC702 ㉞)				PICTURE EFFECT (PK-44 board) (S703)	PROGRAM AE (PK-44 board) (S706)		No key input
17 (KEY AD4) (IC702 ㉟)						FOCUS MANUAL (MF UNIT)	FOCUS AUTO (MF UNIT)

5. Self Diagnosis Log check

Page 3	Address 2A to 3C

Address	Function
2A	Numbers pf error occurrence (0 to 6)
2B	1st error occurrence code
2C	
2D	
2E	2nd error occurrence code
2F	
30	
31	3rd error occurrence code
32	
33	
34	4th error occrrence code
35	
36	
37	5th error occurrence code
38	
39	
3A	6th error occrrence code
3B	
3C	

Example:

C : 32 : 01

- 01 → Address: 2D, 30, 33, 36, 39, 3C
- 32 → Address: 2C, 2F, 32, 35, 38, 3B
- C → Address: 2B, 2E, 31, 34, 37, 3C (Note)

Note: “C” → ”01“
“E“ → “03”

Using method:

1) The self diagnosis log is displayed at page: 3, addresses: 2A to 3C.
   Note: This data will be erased when the coin lithium battery (PK-44 board BH701) is removed (reset).

SECTION 6
REPAIR PARTS LIST

6-1. EXPLODED VIEWS

NOTE:

- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

6-1-1. CABINET (FRONT) SECTION



Note: Refer to sec. 2-6. SERVICE POSITION (see page 2-4) for re-assembling.

Ref. No.	Part No.	Description	Remarks
1	3-968-729-01	SCREW (M2), LOCK ACE, P2	
2	1-959-175-11	HARNESS (RL-51)	
3	3-052-564-01	HOLDER, RL	
4	A-7073-716-A	RL-51 BOARD, COMPLETE	
⚠5	1-418-071-11	FLASH UNIT (50080)	
7	1-418-072-11	BLOCK (50080), MF	
8	X-3949-053-1	GRILLE ASSY, MICROPHONE	
9	3-969-380-01	SPRING, BATTERY	
10	3-050-468-01	SCREW, TRIPOD	
11	X-3949-052-1	SHAFT ASSY, HINGE	
12	X-3949-054-1	CAP ASSY, LENS	
13	X-3949-051-1	CABINET (FRONT) ASSY	
14	3-724-549-01	STRING, CAP	
15	3-736-363-41	TAPPING	
16	3-968-729-51	SCREW (M2), LOCK ACE, P2	
17	X-3949-268-1	LID ASSY, BATTERY	
18	3-713-791-31	SCREW (M1.7X6), TAPPING, P2	
19	3-948-339-61	TAPPING	
20	3-052-574-01	CLAW, BT LOCK	
21	X-3949-269-1	RING ASSY, MF	
J901	1-694-297-31	TERMINAL BOARD, BATTERY	
MIC901	1-542-312-11	MICROPHONE	

6-1-2. CABINET (REAR) SECTION



(Note) The FD block assembly is a mechanical unit which has completely been adjusted in the factory.

Ref. No.	Part No.	Description	Remarks
51	X-3949-050-1	FRAME ASSY, MAIN	
52	1-759-679-11	DRIVE, FLOPPY DISK (3.5 INCH)	
53	3-050-457-01	LID, SIDE	
54	3-050-458-01	SPRING (UPPER), SIDE	
* 55	3-052-567-01	RETAINER, SPEAKER	
56	3-948-339-61	TAPPING	
57	3-352-483-01	SCREW (M2), STEP	
58	3-052-530-01	CABINET, SIDE	
59	3-052-531-01	SHEET METAL (R), STRAP	
60	3-052-606-01	HOLDER, POWER	
61	3-052-598-01	KNOB, EJECT	
62	X-3949-060-1	CABINET (REAR) ASSY	
63	3-052-607-01	LID, LITHIUM	
64	3-052-597-01	LOCK, EJECT	
65	3-052-610-01	SPRING, EJECT	

Ref. No.	Part No.	Description	Remarks
* 66	3-052-609-01	SHEET METAL, EJECT	
67	3-052-537-01	SPRING, EXTENSION	
68	3-978-439-11	BUTTON, CONTROL	
* 69	3-979-292-01	SHEET (CONTROL)	
70	A-7073-717-A	PK-44 (SHP) BOARD, COMPLETE	
71	1-958-571-11	HARNESS (SP-151)	
72	3-713-786-21	SCREW (M2X3)	
73	A-7094-066-A	FC-67 (80) BOARD, COMPLETE	
74	A-7073-719-A	DD-119(80) BOARD, COMPLETE	
75	1-671-864-21	FP-65 (FC-PK) FLEXIBLE BOARD	
76	3-713-791-01	SCREW (M1.7X5), TAPPING, P2	
77	3-050-489-01	COVER, CPC	
LCD901	1-803-036-21	INDICATOR MODULE, LIQUID CRYST	
⚠ ND901	1-517-787-11	TUBE, FLUORESCENT,COLD CATHODE	
SP901	1-529-174-11	SPEAKER (DIA. 20MM)	

Note :	**Note :**
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-1-3. LENS BLOCK SECTION



Be sure to read “Note on the CCD imager replacement” on page 4-7 when changing the CCD Imager.

Ref. No.	Part No.	Description	Remarks
101	1-671-865-11	FP-66 (CD-FC) FLEXIBLE BOARD	
102	3-947-268-11	TITE (2), +B TAPPING (P)	
103	A-7073-715-A	CD-206 BOARD, COMPLETE	
105	3-949-283-01	RUBBER (2), SEAL	
106	1-758-217-11	FILTER BLOCK, OPTICAL	
107	3-957-990-11	ADAPTOR (C), CCD FITTING	
* 108	3-052-563-01	FRAME, LENS	
109	3-948-339-61	TAPPING	
110	8-848-730-01	DEVICE, LENS LSV-550B(SOC)	
IC431	A-7030-955-A	CCD BLOCK ASSY (CCD IMAGER)	

6-2. ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- CAPACITORS:
  uF: µF
- RESISTORS
  All resistors are in ohms.
  METAL: metal-film resistor
  METAL OXIDE: Metal Oxide-film resistor
  F: nonflammable
- COILS
  uH: µH
- SEMICONDUCTORS
  In each case, u: µ, for example:
  uA...: µA... , uPA... , µPA... ,
  uPB... , µPB... , uPC... , µPC... ,
  uPD..., µPD...

When indicating parts by reference number, please include the board name.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

- Abbreviation
  CND : Canadian model
  CN : Chinese model
  AUS : Australian model
  JE : Tourist model
  HK : Hong Kong model

Ref. No.	Part No.	Description			Remarks
	A-7073-715-A	CD-206 BOARD, COMPLETE			
		**********			
		(Ref.No.:2000 Series)			
		(IC431 is not included in this complete board)			
		< CAPACITOR >			
C431	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C434	1-113-981-11	TANTAL. CHIP	22uF	20%	20V
C435	1-135-210-11	TANTALUM CHIP	4.7uF	20%	10V
C436	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
		< CONNECTOR >			
CN431	1-766-346-21	CONNECTOR, FFC/FPC 16P			
		< IC >			
IC431	A-7030-955-A	CCD BLOCK ASSY (CCD IMAGER)			
		< COIL >			
L431	1-414-757-11	INDUCTOR 100uH			
		< TRANSISTOR >			
Q431	8-729-117-73	TRANSISTOR 2SC4178-F13F14-T1			
		< RESISTOR >			
R431	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R432	1-216-809-11	METAL CHIP	100	5%	1/16W
R433	1-216-806-11	RES,CHIP	56	5%	1/16W
R434	1-216-857-11	METAL CHIP	1M	5%	1/16W
R435	1-216-864-11	METAL CHIP	0	5%	1/16W
R436	1-216-295-91	SHORT	0		
	A-7073-719-A	DD-119(80) BOARD, COMPLETE			
		**********			
		(Ref.No.:2000 Series)			
		< CAPACITOR >			
C302	1-164-218-11	CERAMIC CHIP	180PF	0.25PF	50V
C303	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C304	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C305	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C306	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C308	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C309	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C310	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C311	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C314	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V
C315	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C316	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C318	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C319	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C320	1-104-913-11	TANTAL. CHIP	10uF	20%	16V
C321	1-104-913-11	TANTAL. CHIP	10uF	20%	16V
C322	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C323	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C324	1-104-913-11	TANTAL. CHIP	10uF	20%	16V
C325	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C326	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C327	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C328	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C329	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C330	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C331	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C332	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C333	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C334	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C335	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C336	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C337	1-164-506-11	CERAMIC CHIP	4.7uF		16V
C338	1-164-506-11	CERAMIC CHIP	4.7uF		16V
C339	1-164-506-11	CERAMIC CHIP	4.7uF		16V
C340	1-135-214-21	TANTAL. CHIP	4.7uF	20%	20V
C342	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C343	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C344	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C345	1-165-319-11	CERAMIC CHIP	0.1uF		50V
C346	1-165-319-11	CERAMIC CHIP	0.1uF		50V
C347	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C348	1-135-177-21	TANTALUM CHIP	1uF	20%	20V
C349	1-164-337-11	CERAMIC CHIP	2.2uF		16V
C350	1-104-913-11	TANTAL. CHIP	10uF	20%	16V
C352	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C353	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C358	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C359	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C361	1-135-216-11	TANTALUM CHIP	10uF	20%	10V
C364	1-107-682-11	CERAMIC CHIP	1uF	10%	16V

Be sure to read "Note on the CCD imager replacement" on page 4-7 when changing the CCD Imager.

Ref. No.	Part No.	Description	Remarks
		< CONNECTOR >	
CN301	1-580-057-11	PIN, CONNECTOR 4P	
* CN302	1-778-011-42	CONNECTOR, BOARD TO BOARD 50P	
		< DIODE >	
D304	8-719-027-76	DIODE 1SS357-TPH3	
D305	8-719-027-77	DIODE MA796-TX	
D306	8-719-404-49	DIODE MA111-TX	
D307	8-719-404-49	DIODE MA111-TX	
		< FUSE >	
⚠F301	1-533-709-11	FUSE (SMD) (1.25A/24V)	
⚠F302	1-533-709-11	FUSE (SMD) (1.25A/24V)	
⚠F303	1-533-709-11	FUSE (SMD) (1.25A/24V)	
⚠F304	1-533-709-11	FUSE (SMD) (1.25A/24V)	
		< IC >	
IC301	8-759-060-94	IC MB3785APFV-G-BND-ER	
		< COIL >	
L301	1-416-344-11	INDUCTOR 10uH	
L302	1-416-344-11	INDUCTOR 10uH	
L303	1-416-345-11	INDUCTOR 22uH	
L304	1-416-345-11	INDUCTOR 22uH	
L305	1-416-345-11	INDUCTOR 22uH	
L306	1-414-396-21	INDUCTOR 4.7uH	
L307	1-414-392-21	INDUCTOR 1uH	
L308	1-414-396-21	INDUCTOR 4.7uH	
L309	1-414-406-11	INDUCTOR 220uH	
L310	1-414-396-21	INDUCTOR 4.7uH	
L311	1-414-396-21	INDUCTOR 4.7uH	
L312	1-414-396-21	INDUCTOR 4.7uH	
L315	1-414-396-21	INDUCTOR 4.7uH	
L316	1-416-344-11	INDUCTOR 10uH	
L317	1-414-392-21	INDUCTOR 1uH	
		< LINE FILTER >	
LF301	1-411-957-11	FILTER, COMMON MODE	
		< TRANSISTOR >	
Q306	8-729-033-14	TRANSISTOR FP107-TL	
Q307	8-729-804-41	TRANSISTOR 2SB1122-ST-TD	
Q308	8-729-033-14	TRANSISTOR FP107-TL	
Q309	8-729-033-14	TRANSISTOR FP107-TL	
Q310	8-729-037-74	TRANSISTOR UN9213J-(K8).SO	
Q311	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
Q312	8-729-041-23	TRANSISTOR NDS356AP	
Q313	8-729-037-74	TRANSISTOR UN9213J-(K8).SO	
Q314	8-729-037-61	TRANSISTOR RN2104F(TPL3)	
Q315	8-729-037-74	TRANSISTOR UN9213J-(K8).SO	
Q316	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
Q317	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
Q318	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q319	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q320	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
Q321	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
Q322	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q323	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q324	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q325	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q326	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q327	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)	
Q328	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
Q329	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
Q330	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	
		< RESISTOR >	
R309	1-218-871-11	RES,CHIP 10K 0.50% 1/16W	
R310	1-216-850-11	METAL CHIP 270K 5% 1/16W	
R312	1-216-864-11	METAL CHIP 0 5% 1/16W	
R314	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R315	1-218-879-11	RES,CHIP 22K 0.50% 1/16W	
R316	1-218-852-11	RES,CHIP 1.6K 0.50% 1/16W	
R317	1-218-863-11	RES,CHIP 4.7K 0.50% 1/16W	
R318	1-216-840-11	METAL CHIP 39K 5% 1/16W	
R319	1-216-838-11	METAL CHIP 27K 5% 1/16W	
R320	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R321	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R324	1-218-871-11	RES,CHIP 10K 0.50% 1/16W	
R325	1-218-837-11	RES,CHIP 390 0.50% 1/16W	
R326	1-218-871-11	RES,CHIP 10K 0.50% 1/16W	
R327	1-216-847-11	METAL CHIP 150K 5% 1/16W	
R328	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R330	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R331	1-218-871-11	RES,CHIP 10K 0.50% 1/16W	
R332	1-216-864-11	METAL CHIP 0 5% 1/16W	
R333	1-218-871-11	RES,CHIP 10K 0.50% 1/16W	
R334	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R335	1-216-843-11	METAL CHIP 68K 5% 1/16W	
R336	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R337	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R340	1-218-861-11	RES,CHIP 3.9K 0.50% 1/16W	
R341	1-218-871-11	RES,CHIP 10K 0.50% 1/16W	
R342	1-218-863-11	RES,CHIP 4.7K 0.50% 1/16W	
R343	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R346	1-216-813-11	METAL CHIP 220 5% 1/16W	
R347	1-216-819-11	METAL CHIP 680 5% 1/16W	
R348	1-216-817-11	METAL CHIP 470 5% 1/16W	
R349	1-216-817-11	METAL CHIP 470 5% 1/16W	
R352	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R353	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R356	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R357	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R358	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R360	1-218-883-11	RES,CHIP 33K 0.50% 1/16W	
R361	1-216-864-11	METAL CHIP 0 5% 1/16W	
R362	1-218-897-11	RES,CHIP 120K 0.50% 1/16W	
R363	1-218-897-11	RES,CHIP 120K 0.50% 1/16W	
R364	1-216-864-11	METAL CHIP 0 5% 1/16W	
R365	1-216-835-11	METAL CHIP 15K 5% 1/16W	
R366	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R367	1-216-841-11	METAL CHIP 47K 5% 1/16W	

Note :
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Note :
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description			Remarks
R368	1-216-845-11	METAL CHIP	100K	5%	1/16W
R369	1-216-845-11	METAL CHIP	100K	5%	1/16W
R370	1-216-845-11	METAL CHIP	100K	5%	1/16W
R371	1-216-841-11	METAL CHIP	47K	5%	1/16W
R372	1-216-845-11	METAL CHIP	100K	5%	1/16W
R373	1-216-845-11	METAL CHIP	100K	5%	1/16W
R374	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R375	1-216-833-11	METAL CHIP	10K	5%	1/16W
R376	1-218-877-11	RES,CHIP	18K	0.50%	1/16W
R377	1-218-852-11	RES,CHIP	1.6K	5%	1/16W
R378	1-218-897-11	RES,CHIP	120K	0.50%	1/16W
R379	1-218-882-11	RES,CHIP	30K	0.50%	1/16W
R380	1-218-879-11	RES,CHIP	22K	0.50%	1/16W
R381	1-218-891-11	RES,CHIP	68K	0.50%	1/16W
		< TRANSFORMER >			
⚠T301	1-429-565-21	TRANSFORMER, CONVERTER			
	A-7094-066-A	FC-67 (80) BOARD, COMPLETE ********** (Ref.No.:10000 Series)			
		< CAPACITOR >			
C002	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C003	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C004	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C005	1-119-750-11	TANTAL. CHIP	22uF	20%	6.3V
C006	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C007	1-104-913-11	TANTAL. CHIP	10uF	20%	16V
C008	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C009	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C010	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C011	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C012	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C013	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C014	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V
C015	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C016	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C019	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C020	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C021	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C022	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C023	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C024	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C025	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C026	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C027	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C028	1-216-864-11	METAL CHIP	0	5%	1/16W (Note 1)
C030	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V
C031	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C032	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C033	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C034	1-216-848-11	METAL CHIP	180K	5%	1/16W (Note 1)

Ref. No.	Part No.	Description			Remarks
C035	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C037	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C102	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C103	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C104	1-125-839-91	TANTAL. CHIP	47uF	20%	6.3V
C107	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C108	1-135-214-21	TANTAL. CHIP	4.7uF	20%	20V
C109	1-115-156-11	CERAMIC CHIP	1uF		10V
C110	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
C111	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C112	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C113	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C114	1-162-913-11	CERAMIC CHIP	8PF	0.5PF	50V
C116	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C117	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C119	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C120	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C121	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C122	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C123	1-119-750-11	TANTAL. CHIP	22uF	20%	6.3V
C124	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C125	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C126	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C127	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C128	1-110-569-11	TANTAL. CHIP	47uF	20%	6.3V
C129	1-164-346-11	CERAMIC CHIP	1uF		16V
C130	1-162-913-11	CERAMIC CHIP	8PF	0.5PF	50V
C131	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C132	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C135	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C137	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C138	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C139	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C401	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C402	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C403	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C404	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V
C405	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C406	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V
C407	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C408	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
C409	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C410	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C411	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C412	1-104-752-11	TANTAL. CHIP	33uF	20%	6.3V
C413	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C415	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C416	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C417	1-164-346-11	CERAMIC CHIP	1uF		16V
C418	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C419	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C420	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C421	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C451	1-110-569-11	TANTAL. CHIP	47uF	20%	6.3V
C452	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V

Note 1: Resistors are mounted to the location where C028, C034 are printed.

Note :
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Note :
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description			Remarks
C453	1-115-156-11	CERAMIC CHIP	1uF		10V
C454	1-115-156-11	CERAMIC CHIP	1uF		10V
C455	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C456	1-115-156-11	CERAMIC CHIP	1uF		10V
C457	1-115-156-11	CERAMIC CHIP	1uF		10V
C458	1-115-156-11	CERAMIC CHIP	1uF		10V
C459	1-115-156-11	CERAMIC CHIP	1uF		10V
C481	1-115-156-11	CERAMIC CHIP	1uF		10V
C482	1-115-156-11	CERAMIC CHIP	1uF		10V
C483	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C484	1-110-569-11	TANTAL. CHIP	47uF	20%	6.3V
C485	1-115-156-11	CERAMIC CHIP	1uF		10V
C486	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C487	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C488	1-115-156-11	CERAMIC CHIP	1uF		10V
C601	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
C602	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C603	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C604	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C605	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C606	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C607	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C608	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C609	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C610	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C611	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C612	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C701	1-115-156-11	CERAMIC CHIP	1uF		10V
C702	1-115-156-11	CERAMIC CHIP	1uF		10V
C703	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C704	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
C706	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
C707	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C708	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C709	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C713	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C714	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C715	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C716	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C717	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C718	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C720	1-115-156-11	CERAMIC CHIP	1uF		10V
C724	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C725	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V
C726	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
C727	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C728	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C729	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C732	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C733	1-119-750-11	TANTAL. CHIP	22uF	20%	6.3V
C734	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C735	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C736	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C804	1-110-563-11	CERAMIC CHIP	0.068uF	10%	16V
C805	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V

Ref. No.	Part No.	Description			Remarks
C806	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C807	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C808	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V
C809	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C810	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C811	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C812	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V
C813	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C814	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C815	1-115-156-11	CERAMIC CHIP	1uF		10V
C821	1-110-569-11	TANTAL. CHIP	47uF	20%	6.3V
C853	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C856	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C858	1-164-315-11	CERAMIC CHIP	470PF	2%	50V
C859	1-164-315-11	CERAMIC CHIP	470PF	2%	50V
C861	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C862	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C865	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C866	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C867	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C868	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C874	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		< CONNECTOR >			
CN101	1-779-332-11	CONNECTOR, FFC/FPC 16P			
CN401	1-779-334-11	CONNECTOR, FFC/FPC 20P			
CN602	1-785-483-21	CONNECTOR, BOARD TO BOARD 70P			
* CN603	1-766-883-31	CONNECTOR, BOARD TO BOARD 50P			
CN702	1-770-624-21	PIN, CONNECTOR 7P			
CN704	1-770-630-21	PIN, CONNECTOR 13P			
		< DIODE >			
D701	8-719-049-09	DIODE 1SS367-T3SONY			
D702	8-719-404-49	DIODE MA111-TX			
D703	8-719-049-09	DIODE 1SS367-T3SONY			
D706	8-719-061-82	DIODE TLSU1002(TPX1,SONY)			
		< FERRITE BEAD >			
* FB101	1-500-282-11	INDUCTOR CHIP 0UH			
FB102	1-500-283-11	INDUCTOR CHIP 0UH			
FB103	1-414-228-11	INDUCTOR CHIP 0UH			
FB451	1-414-233-21	INDUCTOR CHIP 0UH			
FB452	1-414-228-11	INDUCTOR CHIP 0UH			
FB453	1-414-228-11	INDUCTOR CHIP 0UH			
FB454	1-414-228-11	INDUCTOR CHIP 0UH			
FB455	1-414-228-11	INDUCTOR CHIP 0UH			
FB456	1-414-228-11	INDUCTOR CHIP 0UH			
FB457	1-414-228-11	INDUCTOR CHIP 0UH			
FB481	1-414-233-21	INDUCTOR CHIP 0UH			
FB482	1-414-228-11	INDUCTOR CHIP 0UH			
FB483	1-414-228-11	INDUCTOR CHIP 0UH			
FB484	1-414-228-11	INDUCTOR CHIP 0UH			
FB485	1-414-228-11	INDUCTOR CHIP 0UH			

FC-67

Ref. No.	Part No.	Description			Remarks
FB486	1-414-228-11	INDUCTOR CHIP 0UH			
FB487	1-414-228-11	INDUCTOR CHIP 0UH			
FB488	1-414-228-11	INDUCTOR CHIP 0UH			
FB489	1-414-228-11	INDUCTOR CHIP 0UH			
* FB490	1-216-797-11	METAL CHIP	10	5%	1/16W (Note 1)
* FB491	1-216-797-11	METAL CHIP	10	5%	1/16W (Note 1)
FB801	1-414-233-21	INDUCTOR CHIP 0UH			
FB802	1-414-228-11	INDUCTOR CHIP 0UH			
FB803	1-414-228-11	INDUCTOR CHIP 0UH			
		< IC >			
IC001	8-759-547-46	IC MSM9831-SGX4880MAZ060			
IC002	8-759-075-66	IC TA75S01F(TE85R)			
IC003	8-759-075-66	IC TA75S01F(TE85R)			
IC004	8-759-566-19	IC AK4518VF-E2			
IC006	8-759-494-52	IC BA7783FS-E2			
IC101	8-759-526-24	IC CCD1000Y/T2			
IC102	8-752-395-77	IC CXD2457R-T4			
IC103	8-752-395-76	IC CXD3135R-T6			
IC104	8-759-447-94	IC NJU7201U32-TE1			
IC401	8-759-337-40	IC NJM2904V(TE2)			
IC402	8-759-475-79	IC uPD16833AG3-E2			
IC403	8-752-377-38	IC CXD2430N-T4			
IC404	8-759-338-78	IC BA10324AFV-E2			
IC405	8-759-075-66	IC TA75S01F(TE85R)			
IC451	8-759-543-83	IC KM416V1204CT-L6T			
IC452	8-759-543-83	IC KM416V1204CT-L6T			
IC453	8-752-395-40	IC CXD3138R			
IC481	8-759-564-51	IC KZ4E063G21WFP			
IC601	8-752-384-33	IC CXD3121R-T4			
IC701	8-759-298-10	IC S-8423NFS-T2			
IC702	8-759-572-78	IC S579291PZ-TEB			
IC703	8-759-445-94	IC AK6480AM-E2			
IC704	8-759-364-05	IC M62376GP-65AD			
IC705	8-759-574-31	IC MB90097PFV-G-116-BND-ER			
IC801	8-759-458-76	IC uPD72069GF-3BA			
IC802	8-759-196-97	IC TC7SH32FU-TE85R			
IC803	8-759-466-32	IC TA8563FN(EL)			
IC804	8-759-475-48	IC TC74LCX245FT(EL)			
IC805	8-759-083-94	IC TC7W74FU(TE12R)			
IC851	8-759-564-97	IC HD6417708SF60			
IC852	8-759-565-13	IC MBM29LV200B-10PFTN-025-ER			
		< COIL >			
L001	1-414-754-11	INDUCTOR 10uH			
L002	1-414-754-11	INDUCTOR 10uH			
L003	1-414-406-11	INDUCTOR 220uH			
L004	1-414-754-11	INDUCTOR 10uH			
L005	1-414-754-11	INDUCTOR 10uH			
L007	1-414-754-11	INDUCTOR 10uH			
L101	1-414-754-11	INDUCTOR 10uH			
L102	1-414-754-11	INDUCTOR 10uH			
L103	1-414-754-11	INDUCTOR 10uH			
L104	1-414-754-11	INDUCTOR 10uH			

Ref. No.	Part No.	Description			Remarks
L401	1-414-078-11	INDUCTOR 10uH			
L402	1-414-754-11	INDUCTOR 10uH			
L403	1-414-078-11	INDUCTOR 10uH			
L451	1-414-402-11	INDUCTOR 47uH			
L452	1-414-402-11	INDUCTOR 47uH			
L601	1-412-951-11	INDUCTOR 10uH			
L602	1-412-963-21	INDUCTOR 100uH			
L603	1-412-963-21	INDUCTOR 100uH			
L604	1-412-963-21	INDUCTOR 100uH			
L701	1-414-754-11	INDUCTOR 10uH			
L702	1-414-757-11	INDUCTOR 100uH			
L703	1-414-757-11	INDUCTOR 100uH			
L801	1-414-754-11	INDUCTOR 10uH			
L802	1-414-402-11	INDUCTOR 47uH			
L803	1-414-402-11	INDUCTOR 47uH			
		< TRANSISTOR >			
Q101	8-729-037-61	TRANSISTOR RN2104F(TPL3)			
Q102	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q103	8-729-037-61	TRANSISTOR RN2104F(TPL3)			
Q104	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q401	8-729-037-53	TRANSISTOR 2SB1462J-QR(TX).SO			
Q402	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO			
Q403	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO			
Q601	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO			
Q602	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO			
Q603	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO			
Q701	8-729-024-48	TRANSISTOR 2SK1830-TE85L			
Q702	8-729-032-62	TRANSISTOR 2SJ347-TE85L			
Q703	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q704	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q705	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q706	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q707	8-729-037-52	TRANSISTOR 2SD2216J-QR(TX).SO			
Q708	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q801	8-729-037-61	TRANSISTOR RN2104F(TPL3)			
Q802	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q803	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q804	8-729-037-53	TRANSISTOR 2SB1462J-QR(TX).SO			
Q805	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q1005	8-729-015-66	TRANSISTOR 2SC4919			
		< RESISTOR >			
R007	1-216-864-11	METAL CHIP	0	5%	1/16W
R008	1-216-852-11	METAL CHIP	390K	5%	1/16W
R009	1-216-833-11	METAL CHIP	10K	5%	1/16W
R010	1-216-837-11	METAL CHIP	22K	5%	1/16W
R011	1-216-821-11	METAL CHIP	1K	5%	1/16W
R012	1-216-833-11	METAL CHIP	10K	5%	1/16W
R014	1-216-838-11	METAL CHIP	27K	5%	1/16W
R016	1-216-844-11	METAL CHIP	82K	5%	1/16W
R017	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R019	1-216-851-11	METAL CHIP	330K	5%	1/16W
R020	1-216-848-11	METAL CHIP	180K	5%	1/16W
R021	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R022	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R024	1-216-817-11	METAL CHIP	470	5%	1/16W
R025	1-216-864-11	METAL CHIP	0	5%	1/16W

Note 1: Resistors are mounted to the location where FB490, FB491 are printed.

Ref. No.	Part No.	Description			Remarks
R026	1-216-864-11	METAL CHIP	0	5%	1/16W
R028	1-216-840-11	METAL CHIP	39K	5%	1/16W
R029	1-216-833-11	METAL CHIP	10K	5%	1/16W
R031	1-216-864-11	METAL CHIP	0	5%	1/16W
R032	1-216-864-11	METAL CHIP	0	5%	1/16W
R035	1-216-846-11	METAL CHIP	120K	5%	1/16W
R037	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R040	1-216-864-11	METAL CHIP	0	5%	1/16W
R042	1-216-864-11	METAL CHIP	0	5%	1/16W
R102	1-216-845-11	METAL CHIP	100K	5%	1/16W
R103	1-216-864-11	METAL CHIP	0	5%	1/16W
R104	1-216-864-11	METAL CHIP	0	5%	1/16W
R106	1-216-864-11	METAL CHIP	0	5%	1/16W
R111	1-216-841-11	METAL CHIP	47K	5%	1/16W
R112	1-216-833-11	METAL CHIP	10K	5%	1/16W
R113	1-216-864-11	METAL CHIP	0	5%	1/16W
R115	1-216-864-11	METAL CHIP	0	5%	1/16W
R116	1-216-864-11	METAL CHIP	0	5%	1/16W
R117	1-216-864-11	METAL CHIP	0	5%	1/16W
R118	1-216-864-11	METAL CHIP	0	5%	1/16W
R119	1-216-841-11	METAL CHIP	47K	5%	1/16W
R120	1-216-864-11	METAL CHIP	0	5%	1/16W
R121	1-216-806-11	RES,CHIP	56	5%	1/16W
R122	1-216-864-11	METAL CHIP	0	5%	1/16W
R124	1-216-864-11	METAL CHIP	0	5%	1/16W
R132	1-216-864-11	METAL CHIP	0	5%	1/16W
R133	1-216-864-11	METAL CHIP	0	5%	1/16W
R134	1-216-864-11	METAL CHIP	0	5%	1/16W
R135	1-216-864-11	METAL CHIP	0	5%	1/16W
R136	1-216-864-11	METAL CHIP	0	5%	1/16W
R137	1-216-864-11	METAL CHIP	0	5%	1/16W
R139	1-216-864-11	METAL CHIP	0	5%	1/16W
R140	1-216-864-11	METAL CHIP	0	5%	1/16W
R141	1-216-864-11	METAL CHIP	0	5%	1/16W
R401	1-216-841-11	METAL CHIP	47K	5%	1/16W
R402	1-216-797-11	METAL CHIP	10	5%	1/16W
R403	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R404	1-216-843-11	METAL CHIP	68K	5%	1/16W
R405	1-216-843-11	METAL CHIP	68K	5%	1/16W
R406	1-216-821-11	METAL CHIP	1K	5%	1/16W
R407	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R408	1-216-845-11	METAL CHIP	100K	5%	1/16W
R409	1-216-833-11	METAL CHIP	10K	5%	1/16W
R410	1-216-845-11	METAL CHIP	100K	5%	1/16W
R411	1-216-837-11	METAL CHIP	22K	5%	1/16W
R412	1-216-815-11	METAL CHIP	330	5%	1/16W
R413	1-216-837-11	METAL CHIP	22K	5%	1/16W
R414	1-216-845-11	METAL CHIP	100K	5%	1/16W
R415	1-216-821-11	METAL CHIP	1K	5%	1/16W
R416	1-216-837-11	METAL CHIP	22K	5%	1/16W
R417	1-216-848-11	METAL CHIP	180K	5%	1/16W
R418	1-216-833-11	METAL CHIP	10K	5%	1/16W
R419	1-216-836-11	METAL CHIP	18K	5%	1/16W
R420	1-216-845-11	METAL CHIP	100K	5%	1/16W
R422	1-216-848-11	METAL CHIP	180K	5%	1/16W
R423	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R424	1-216-851-11	METAL CHIP	330K	5%	1/16W
R425	1-218-887-11	RES,CHIP	47K	0.50%	1/16W
R426	1-218-877-11	RES,CHIP	18K	0.50%	1/16W
R428	1-216-821-11	METAL CHIP	1K	5%	1/16W
R429	1-218-876-11	RES,CHIP	16K	0.50%	1/16W
R430	1-216-295-91	SHORT	0		
R451	1-216-864-11	METAL CHIP	0	5%	1/16W
R452	1-216-864-11	METAL CHIP	0	5%	1/16W
R453	1-216-864-11	METAL CHIP	0	5%	1/16W
R454	1-216-864-11	METAL CHIP	0	5%	1/16W
R455	1-216-857-11	METAL CHIP	1M	5%	1/16W
R456	1-216-845-11	METAL CHIP	100K	5%	1/16W
R457	1-216-833-11	METAL CHIP	10K	5%	1/16W
R601	1-216-835-11	METAL CHIP	15K	5%	1/16W
R605	1-216-835-11	METAL CHIP	15K	5%	1/16W
R606	1-216-835-11	METAL CHIP	15K	5%	1/16W
R610	1-216-821-11	METAL CHIP	1K	5%	1/16W
R611	1-216-840-11	METAL CHIP	39K	5%	1/16W
R612	1-216-834-11	METAL CHIP	12K	5%	1/16W
R614	1-216-821-11	METAL CHIP	1K	5%	1/16W
R615	1-216-821-11	METAL CHIP	1K	5%	1/16W
R616	1-216-840-11	METAL CHIP	39K	5%	1/16W
R617	1-216-834-11	METAL CHIP	12K	5%	1/16W
R619	1-216-821-11	METAL CHIP	1K	5%	1/16W
R620	1-216-821-11	METAL CHIP	1K	5%	1/16W
R621	1-216-840-11	METAL CHIP	39K	5%	1/16W
R622	1-216-834-11	METAL CHIP	12K	5%	1/16W
R624	1-216-821-11	METAL CHIP	1K	5%	1/16W
R630	1-216-864-11	METAL CHIP	0	5%	1/16W
R701	1-216-845-11	METAL CHIP	100K	5%	1/16W
R702	1-216-813-11	METAL CHIP	220	5%	1/16W
R703	1-216-833-11	METAL CHIP	10K	5%	1/16W
R704	1-216-853-11	METAL CHIP	470K	5%	1/16W
R706	1-216-853-11	METAL CHIP	470K	5%	1/16W
R707	1-216-845-11	METAL CHIP	100K	5%	1/16W
R708	1-216-845-11	METAL CHIP	100K	5%	1/16W
R709	1-216-845-11	METAL CHIP	100K	5%	1/16W
R710	1-216-845-11	METAL CHIP	100K	5%	1/16W
R711	1-216-845-11	METAL CHIP	100K	5%	1/16W
R712	1-216-853-11	METAL CHIP	470K	5%	1/16W
R714	1-216-853-11	METAL CHIP	470K	5%	1/16W
R715	1-216-841-11	METAL CHIP	47K	5%	1/16W
R716	1-216-821-11	METAL CHIP	1K	5%	1/16W
R717	1-216-833-11	METAL CHIP	10K	5%	1/16W
R718	1-216-853-11	METAL CHIP	470K	5%	1/16W
R719	1-216-837-11	METAL CHIP	22K	5%	1/16W
R720	1-216-839-11	METAL CHIP	33K	5%	1/16W
R721	1-216-821-11	METAL CHIP	1K	5%	1/16W
R722	1-216-821-11	METAL CHIP	1K	5%	1/16W
R723	1-216-821-11	METAL CHIP	1K	5%	1/16W
R724	1-216-821-11	METAL CHIP	1K	5%	1/16W
R725	1-216-821-11	METAL CHIP	1K	5%	1/16W
R726	1-216-853-11	METAL CHIP	470K	5%	1/16W
R727	1-216-833-11	METAL CHIP	10K	5%	1/16W

Ref. No.	Part No.	Description			Remarks
R728	1-216-833-11	METAL CHIP	10K	5%	1/16W
R729	1-216-833-11	METAL CHIP	10K	5%	1/16W
R730	1-216-821-11	METAL CHIP	1K	5%	1/16W
R731	1-216-833-11	METAL CHIP	10K	5%	1/16W
R736	1-216-841-11	METAL CHIP	47K	5%	1/16W
R737	1-216-821-11	METAL CHIP	1K	5%	1/16W
R738	1-216-821-11	METAL CHIP	1K	5%	1/16W
R739	1-216-821-11	METAL CHIP	1K	5%	1/16W
R740	1-216-821-11	METAL CHIP	1K	5%	1/16W
R741	1-216-853-11	METAL CHIP	470K	5%	1/16W
R742	1-219-570-11	RES,CHIP	10M	5%	1/16W
R743	1-216-853-11	METAL CHIP	470K	5%	1/16W
R744	1-216-864-11	METAL CHIP	0	5%	1/16W
R745	1-216-849-11	METAL CHIP	220K	5%	1/16W
R746	1-216-845-11	METAL CHIP	100K	5%	1/16W
R747	1-216-817-11	METAL CHIP	470	5%	1/16W
R749	1-216-853-11	METAL CHIP	470K	5%	1/16W
R751	1-216-845-11	METAL CHIP	100K	5%	1/16W
R752	1-216-821-11	METAL CHIP	1K	5%	1/16W
R753	1-216-833-11	METAL CHIP	10K	5%	1/16W
R754	1-216-845-11	METAL CHIP	100K	5%	1/16W
R755	1-216-845-11	METAL CHIP	100K	5%	1/16W
R757	1-216-864-11	METAL CHIP	0	5%	1/16W
R759	1-216-857-11	METAL CHIP	1M	5%	1/16W
R761	1-216-833-11	METAL CHIP	10K	5%	1/16W
R762	1-216-821-11	METAL CHIP	1K	5%	1/16W
R763	1-216-821-11	METAL CHIP	1K	5%	1/16W
R764	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R765	1-216-864-11	METAL CHIP	0	5%	1/16W
R769	1-216-845-11	METAL CHIP	100K	5%	1/16W
R770	1-216-864-11	METAL CHIP	0	5%	1/16W
R771	1-216-864-11	METAL CHIP	0	5%	1/16W
R772	1-216-864-11	METAL CHIP	0	5%	1/16W
R775	1-216-845-11	METAL CHIP	100K	5%	1/16W
R776	1-216-857-11	METAL CHIP	1M	5%	1/16W
R777	1-216-853-11	METAL CHIP	470K	5%	1/16W
R778	1-216-819-11	METAL CHIP	680	5%	1/16W
R779	1-216-845-11	METAL CHIP	100K	5%	1/16W
R780	1-216-845-11	METAL CHIP	100K	5%	1/16W
R781	1-216-864-11	METAL CHIP	0	5%	1/16W
R784	1-216-864-11	METAL CHIP	0	5%	1/16W
R785	1-216-864-11	METAL CHIP	0	5%	1/16W
R786	1-216-864-11	METAL CHIP	0	5%	1/16W
R802	1-216-864-11	METAL CHIP	0	5%	1/16W
R804	1-216-864-11	METAL CHIP	0	5%	1/16W
R806	1-216-821-11	METAL CHIP	1K	5%	1/16W
R807	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R808	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R809	1-218-878-11	RES,CHIP	20K	0.50%	1/16W
R810	1-218-854-11	RES,CHIP	2K	0.50%	1/16W
R811	1-216-833-11	METAL CHIP	10K	5%	1/16W
R812	1-216-821-11	METAL CHIP	1K	5%	1/16W
R813	1-216-821-11	METAL CHIP	1K	5%	1/16W
R814	1-216-821-11	METAL CHIP	1K	5%	1/16W
R815	1-216-833-11	METAL CHIP	10K	5%	1/16W

Ref. No.	Part No.	Description			Remarks
R816	1-216-833-11	METAL CHIP	10K	5%	1/16W
R817	1-216-833-11	METAL CHIP	10K	5%	1/16W
R818	1-216-833-11	METAL CHIP	10K	5%	1/16W
R819	1-216-833-11	METAL CHIP	10K	5%	1/16W
R820	1-216-833-11	METAL CHIP	10K	5%	1/16W
R821	1-216-833-11	METAL CHIP	10K	5%	1/16W
R822	1-216-833-11	METAL CHIP	10K	5%	1/16W
R823	1-216-833-11	METAL CHIP	10K	5%	1/16W
R824	1-216-864-11	METAL CHIP	0	5%	1/16W
R825	1-216-833-11	METAL CHIP	10K	5%	1/16W
R826	1-216-853-11	METAL CHIP	470K	5%	1/16W
R827	1-216-841-11	METAL CHIP	47K	5%	1/16W
R828	1-216-864-11	METAL CHIP	0	5%	1/16W
R830	1-216-833-11	METAL CHIP	10K	5%	1/16W
R831	1-216-833-11	METAL CHIP	10K	5%	1/16W
R832	1-216-835-11	METAL CHIP	15K	5%	1/16W
R855	1-216-845-11	METAL CHIP	100K	5%	1/16W
R856	1-216-845-11	METAL CHIP	100K	5%	1/16W
R857	1-216-845-11	METAL CHIP	100K	5%	1/16W
R858	1-216-864-11	METAL CHIP	0	5%	1/16W
R863	1-216-857-11	METAL CHIP	1M	5%	1/16W
R868	1-216-845-11	METAL CHIP	100K	5%	1/16W
R870	1-216-857-11	METAL CHIP	1M	5%	1/16W
R871	1-216-845-11	METAL CHIP	100K	5%	1/16W
R876	1-216-841-11	METAL CHIP	47K	5%	1/16W
R877	1-216-841-11	METAL CHIP	47K	5%	1/16W
R878	1-216-841-11	METAL CHIP	47K	5%	1/16W
R879	1-216-841-11	METAL CHIP	47K	5%	1/16W
R880	1-216-841-11	METAL CHIP	47K	5%	1/16W
R881	1-216-841-11	METAL CHIP	47K	5%	1/16W
R882	1-216-841-11	METAL CHIP	47K	5%	1/16W
R883	1-216-841-11	METAL CHIP	47K	5%	1/16W
R884	1-216-841-11	METAL CHIP	47K	5%	1/16W
R887	1-216-864-11	METAL CHIP	0	5%	1/16W
R888	1-216-864-11	METAL CHIP	0	5%	1/16W
R889	1-216-864-11	METAL CHIP	0	5%	1/16W
R890	1-216-864-11	METAL CHIP	0	5%	1/16W
R891	1-216-845-11	METAL CHIP	100K	5%	1/16W
R892	1-216-845-11	METAL CHIP	100K	5%	1/16W
R893	1-216-845-11	METAL CHIP	100K	5%	1/16W
R894	1-216-845-11	METAL CHIP	100K	5%	1/16W
R895	1-216-845-11	METAL CHIP	100K	5%	1/16W
R896	1-216-845-11	METAL CHIP	100K	5%	1/16W
R897	1-216-833-11	METAL CHIP	10K	5%	1/16W
R898	1-216-841-11	METAL CHIP	47K	5%	1/16W
R899	1-216-845-11	METAL CHIP	100K	5%	1/16W
		< SHOCK SENSOR >			
SE801	1-801-868-41	SENSOR, SHOCK			
		< VIBRATOR >			
X101	1-781-158-21	VIBRATOR, CERAMIC (33.528MHz)			
X451	1-781-160-21	VIBRATOR, CERAMIC (16.384MHz)			
X701	1-767-450-11	VIBRATOR, CERAMIC (20MHz)			
X702	1-760-458-21	VIBRATOR, CRYSTAL (32.768KHz)			
X802	1-781-069-21	VIBRATOR, CERAMIC (6.875 MHz)			
X803	1-767-922-11	VIBRATOR, CERAMIC (16MHz)			

Ref. No.	Part No.	Description			Remarks
	A-7073-717-A	PK-44 (SHP) BOARD, COMPLETE			
		**********			
		(Ref.No.:2000 Series)			
		< BATTERY HOLDER >			
BH701	1-550-104-32	HOLDER, BATTERY			
		< CAPACITOR >			
C601	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C602	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C603	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C604	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C605	1-113-642-11	TANTAL. CHIP	47uF	20%	10V
C606	1-113-642-11	TANTAL. CHIP	47uF	20%	10V
C801	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C802	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C803	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C804	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C805	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C806	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C807	1-110-569-11	TANTAL. CHIP	47uF	20%	6.3V
C808	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C810	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C811	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C812	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C813	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C814	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C815	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C816	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C817	1-135-149-21	TANTALUM CHIP	2.2uF	20%	10V
C851	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C852	1-113-981-11	TANTAL. CHIP	22uF	20%	20V
C853	1-163-081-00	CERAMIC CHIP	0.22uF		25V
C854	1-135-149-21	TANTALUM CHIP	2.2uF	20%	10V
C855	1-164-505-11	CERAMIC CHIP	2.2uF		16V
C856	1-162-918-11	CERAMIC CHIP	18PF	5%	50V
C857	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C858	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C859	1-162-920-11	CERAMIC CHIP	27PF	5%	50V
C861	1-104-911-11	TANTAL. CHIP	33uF	20%	10V
C862	1-164-346-11	CERAMIC CHIP	1uF		16V
C863	1-164-661-11	CERAMIC CHIP	0.018uF	10%	50V
C865	1-107-725-11	CERAMIC CHIP	0.1uF	10%	16V
⚠C866	1-113-521-11	CERAMIC CHIP	12PF	10%	3KV
C867	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C902	1-107-687-11	TANTAL. CHIP	3.3uF	20%	20V
C903	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C904	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C905	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C906	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C907	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C908	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C909	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C911	1-164-739-11	CERAMIC CHIP	560PF	5%	50V
C913	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C915	1-107-682-11	CERAMIC CHIP	1uF	10%	16V
C916	1-113-994-11	TANTAL. CHIP	6.8uF	20%	16V
C917	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C918	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C919	1-107-689-21	TANTAL. CHIP	1uF	20%	35V
C920	1-107-682-11	CERAMIC CHIP	1uF	10%	16V
C926	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		< CONNECTOR >			
CN601	1-764-526-11	CONNECTOR, FFC/FPC 18P			
* CN602	1-750-075-11	CONNECTOR, FFC/FPC 10P			
CN603	1-785-482-21	CONNECTOR, BOARD TO BOARD 70P			
CN701	1-778-506-21	PIN, CONNECTOR (PC BOARD) 2P			
CN802	1-764-526-11	CONNECTOR, FFC/FPC 18P			
CN851	1-691-384-11	CONNECTOR, FFC/FPC 20P			
CN901	1-691-388-11	CONNECTOR, FFC/FPC 24P			
		< DIODE >			
D601	8-719-404-49	DIODE MA111-TX			
D701	8-719-061-82	DIODE TLSU1002(TPX1,SONY)			
D702	8-719-061-81	DIODE TLYU1002(TPX1,SONY)			
D708	8-719-404-49	DIODE MA111-TX			
D715	8-719-064-05	DIODE TLGU1002(TPX1,SONY)			
D852	8-719-404-49	DIODE MA111-TX			
D853	8-719-404-49	DIODE MA111-TX			
D903	8-713-102-80	DIODE 1T369-01-T8A			
D904	8-719-976-96	DIODE MA8047-H-TX			
		< IC >			
IC601	8-759-535-05	IC BH9530KS2			
IC801	8-759-530-19	IC MB40D001PFV-G-BND-ER			
IC802	8-759-539-27	IC IR3Y37A4			
IC851	8-759-521-35	IC TL5001CDR			
IC852	8-759-075-70	IC TA75S393F-TE85R			
IC901	8-759-495-00	IC LZ9GH184			
IC902	8-759-327-01	IC NJM062V(TE2)			
IC903	8-759-523-03	IC TC74HC4066AFT(EL)			
		< COIL >			
L601	1-414-397-11	INDUCTOR 6.8uH			
L801	1-414-757-11	INDUCTOR 100uH			
L802	1-414-078-11	INDUCTOR 10uH			
L851	1-414-396-21	INDUCTOR 4.7uH			
L852	1-424-674-11	INDUCTOR 0uH			
L853	1-409-536-41	INDUCTOR 0uH			
L901	1-414-754-11	INDUCTOR 10uH			
L902	1-414-754-11	INDUCTOR 10uH			
L903	1-412-951-11	INDUCTOR 10uH			
L905	1-412-955-11	INDUCTOR 22uH			
		< TRANSISTOR >			
Q851	8-729-042-72	TRANSISTOR UN9214J-(K8).SO			
Q852	8-729-042-59	TRANSISTOR UN9112J-(K8).SO			
Q853	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q854	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)			
Q855	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q856	8-729-823-84	TRANSISTOR FP102-TL			
Q857	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)			
Q858	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)			
Q859	8-729-037-74	TRANSISTOR UN9213J-(K8).SO			
Q860	8-729-039-43	TRANSISTOR FP216-TL			

Note :
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Note :
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

PK-44

Ref. No.	Part No.	Description			Remarks
Q862	8-729-042-59	TRANSISTOR	UN9112J-(K8).SO		
Q903	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX		
Q904	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX		
Q905	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX		
Q906	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX		
		< RESISTOR >			
R601	1-216-033-00	METAL CHIP	220	5%	1/10W
R602	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R603	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R604	1-216-845-11	METAL CHIP	100K	5%	1/16W
R605	1-216-298-00	METAL CHIP	2.2	5%	1/10W
R606	1-218-707-11	RES,CHIP	4.3K	5%	1/16W
R607	1-218-707-11	RES,CHIP	4.3K	5%	1/16W
R608	1-216-864-11	METAL CHIP	0	5%	1/16W
R610	1-216-864-11	METAL CHIP	0	5%	1/16W
R612	1-218-851-11	RES,CHIP	1.5K	0.50%	1/16W
R613	1-218-869-11	RES,CHIP	8.2K	0.50%	1/16W
R614	1-218-863-11	RES,CHIP	4.7K	0.50%	1/16W
R615	1-218-859-11	RES,CHIP	3.3K	0.50%	1/16W
R618	1-218-887-11	RES,CHIP	47K	0.50%	1/16W
R619	1-218-849-11	RES,CHIP	1.2K	0.50%	1/16W
R620	1-216-821-11	METAL CHIP	1K	5%	1/16W
R621	1-218-847-11	RES,CHIP	1K	0.50%	1/16W
R622	1-218-875-11	RES,CHIP	15K	0.50%	1/16W
R623	1-218-292-11	RES,CHIP	20K	5%	1/16W
R624	1-216-817-11	METAL CHIP	470	5%	1/16W
R625	1-216-833-11	METAL CHIP	10K	5%	1/16W
R626	1-216-835-11	METAL CHIP	15K	5%	1/16W
R627	1-216-833-11	METAL CHIP	10K	5%	1/16W
R628	1-216-835-11	METAL CHIP	15K	5%	1/16W
R629	1-216-835-11	METAL CHIP	15K	5%	1/16W
R630	1-216-833-11	METAL CHIP	10K	5%	1/16W
R631	1-216-857-11	METAL CHIP	1M	5%	1/16W
R632	1-216-833-11	METAL CHIP	10K	5%	1/16W
R701	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R702	1-216-819-11	METAL CHIP	680	5%	1/16W
R703	1-216-819-11	METAL CHIP	680	5%	1/16W
R704	1-216-841-11	METAL CHIP	47K	5%	1/16W
R705	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R706	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R707	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R708	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R709	1-216-819-11	METAL CHIP	680	5%	1/16W
R710	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R711	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
R712	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R713	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R714	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R715	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R716	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R722	1-216-833-11	METAL CHIP	10K	5%	1/16W
R729	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R801	1-216-840-11	METAL CHIP	39K	5%	1/16W
R804	1-216-837-11	METAL CHIP	22K	5%	1/16W
R805	1-216-834-11	METAL CHIP	12K	5%	1/16W
R806	1-216-841-11	METAL CHIP	47K	5%	1/16W

Ref. No.	Part No.	Description			Remarks
R812	1-216-845-11	METAL CHIP	100K	5%	1/16W
R813	1-216-805-11	METAL CHIP	47	5%	1/16W
R814	1-216-805-11	METAL CHIP	47	5%	1/16W
R815	1-216-805-11	METAL CHIP	47	5%	1/16W
R817	1-216-833-11	METAL CHIP	10K	5%	1/16W
R820	1-216-839-11	METAL CHIP	33K	5%	1/16W
R821	1-216-841-11	METAL CHIP	47K	5%	1/16W
R822	1-216-840-11	METAL CHIP	39K	5%	1/16W
R823	1-216-834-11	METAL CHIP	12K	5%	1/16W
R824	1-216-848-11	METAL CHIP	180K	5%	1/16W
R825	1-216-864-11	METAL CHIP	0	5%	1/16W
R827	1-216-835-11	METAL CHIP	15K	5%	1/16W
R828	1-216-839-11	METAL CHIP	33K	5%	1/16W
R830	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R852	1-218-867-11	RES,CHIP	6.8K	0.50%	1/16W
R853	1-218-881-11	RES,CHIP	27K	0.50%	1/16W
R854	1-218-897-11	RES,CHIP	120K	0.50%	1/16W
R855	1-216-818-11	METAL CHIP	560	5%	1/16W
R856	1-216-837-11	METAL CHIP	22K	5%	1/16W
R857	1-216-818-11	METAL CHIP	560	5%	1/16W
R858	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R859	1-218-871-11	RES,CHIP	10K	0.50%	1/16W
R860	1-218-853-11	RES,CHIP	1.8K	0.50%	1/16W
R861	1-218-859-11	RES,CHIP	3.3K	0.50%	1/16W
R862	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R863	1-216-841-11	METAL CHIP	47K	5%	1/16W
R864	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R865	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R867	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R868	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R870	1-216-845-11	METAL CHIP	100K	5%	1/16W
R871	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
R872	1-216-837-11	METAL CHIP	22K	5%	1/16W
R873	1-216-817-11	METAL CHIP	470	5%	1/16W
R874	1-216-810-11	METAL CHIP	120	5%	1/16W
R903	1-216-864-11	METAL CHIP	0	5%	1/16W
R905	1-216-855-11	METAL CHIP	680K	5%	1/16W
R908	1-216-846-11	METAL CHIP	120K	5%	1/16W
R909	1-216-846-11	METAL CHIP	120K	5%	1/16W
R910	1-216-864-11	METAL CHIP	0	5%	1/16W
R912	1-216-845-11	METAL CHIP	100K	5%	1/16W
R913	1-216-833-11	METAL CHIP	10K	5%	1/16W
R914	1-216-857-11	METAL CHIP	1M	5%	1/16W
R915	1-216-857-11	METAL CHIP	1M	5%	1/16W
R916	1-216-837-11	METAL CHIP	22K	5%	1/16W
R918	1-216-843-11	METAL CHIP	68K	5%	1/16W
R920	1-218-901-11	RES,CHIP	180K	0.50%	1/16W
R921	1-216-843-11	METAL CHIP	68K	5%	1/16W
R922	1-216-841-11	METAL CHIP	47K	5%	1/16W
R924	1-218-901-11	RES,CHIP	180K	0.50%	1/16W
R926	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R927	1-216-864-11	METAL CHIP	0	5%	1/16W
R929	1-216-845-11	METAL CHIP	100K	5%	1/16W
R930	1-216-839-11	METAL CHIP	33K	5%	1/16W
R931	1-216-864-11	METAL CHIP	0	5%	1/16W

Ref. No.	Part No.	Description			Remarks
R932	1-216-845-11	METAL CHIP	100K	5%	1/16W
R933	1-216-845-11	METAL CHIP	100K	5%	1/16W
R934	1-216-864-11	METAL CHIP	0	5%	1/16W
R935	1-216-864-11	METAL CHIP	0	5%	1/16W
R938	1-216-845-11	METAL CHIP	100K	5%	1/16W
R939	1-216-839-11	METAL CHIP	33K	5%	1/16W
R940	1-216-864-11	METAL CHIP	0	5%	1/16W
R941	1-218-883-11	RES,CHIP	33K	0.50%	1/16W
R942	1-218-879-11	RES,CHIP	22K	0.50%	1/16W
R943	1-218-883-11	RES,CHIP	33K	0.50%	1/16W
R944	1-218-879-11	RES,CHIP	22K	0.50%	1/16W
R945	1-216-864-11	METAL CHIP	0	5%	1/16W
R946	1-216-864-11	METAL CHIP	0	5%	1/16W
R947	1-216-864-11	METAL CHIP	0	5%	1/16W
R948	1-216-864-11	METAL CHIP	0	5%	1/16W
R949	1-216-864-11	METAL CHIP	0	5%	1/16W
R956	1-216-864-11	METAL CHIP	0	5%	1/16W
R958	1-216-864-11	METAL CHIP	0	5%	1/16W
R960	1-216-864-11	METAL CHIP	0	5%	1/16W
R961	1-216-864-11	METAL CHIP	0	5%	1/16W
R964	1-216-864-11	METAL CHIP	0	5%	1/16W
R965	1-216-864-11	METAL CHIP	0	5%	1/16W
R967	1-216-805-11	METAL CHIP	47	5%	1/16W
R968	1-216-805-11	METAL CHIP	47	5%	1/16W
R969	1-216-805-11	METAL CHIP	47	5%	1/16W
R974	1-216-864-11	METAL CHIP	0	5%	1/16W
R975	1-216-864-11	METAL CHIP	0	5%	1/16W
R978	1-216-841-11	METAL CHIP	47K	5%	1/16W
R979	1-216-841-11	METAL CHIP	47K	5%	1/16W
R980	1-216-864-11	METAL CHIP	0	5%	1/16W
R981	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R988	1-216-864-11	METAL CHIP	0	5%	1/16W
		< VARIABLE RESISTOR >			
RV701	1-225-224-11	RES, VAR (ZOOM) 10K (ZOOM)			
		< SWITCH >			
S701	1-771-128-11	SWITCH, TACTILE (CONTROL SWITCH)			
S702	1-572-467-21	SWITCH, PUSH (1 KEY)(POWER)			
S703	1-771-106-11	SWITCH, TACTILE (PICTURE EFFECT)			
S704	1-771-106-11	SWITCH, TACTILE (DISPLAY)			
S705	1-771-106-11	SWITCH, TACTILE (VOLUME +)			
S706	1-771-106-11	SWITCH, TACTILE (PROGRAM AE)			
S707	1-771-106-11	SWITCH, TACTILE (FLASH/VOICE MEMO)			
S708	1-572-467-21	SWITCH, PUSH (1 KEY)(PLAY/CAMERA/MOVIE)			
S709	1-771-106-11	SWITCH, TACTILE (VOLUME -)			
S710	1-762-741-11	SWITCH, SLIDE (BACK LIGHT)			
S712	1-572-467-21	SWITCH, PUSH (1 KEY)(PLAY/CAMERA/MOVIE)			
S715	1-771-106-11	SWITCH, TACTILE (BRIGHT -)			
S716	1-771-106-11	SWITCH, TACTILE (BRIGHT +)			
		< TRANSFORMER >			
⚠T851	1-431-861-21	TRANSFORMER, INVERTER			

Ref. No.	Part No.	Description			Remarks
		< VIBRATOR >			
X601	1-760-496-21	VIBRATOR, LITHIUM NIOBATE (4MHz)			
	A-7073-716-A	RL-51 BOARD, COMPLETE			
		**********			
					(Ref.No.:2000 Series)
		< CAPACITOR >			
C001	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
C002	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C003	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C004	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
C005	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
C006	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C007	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C009	1-135-091-00	TANTALUM CHIP	1uF	20%	16V
C010	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C011	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C012	1-135-179-21	TANTAL. CHIP	2.2uF	20%	16V
C013	1-119-750-11	TANTAL. CHIP	22uF	20%	6.3V
		< CONNECTOR >			
CN001	1-580-055-21	PIN, CONNECTOR 2P			
CN002	1-770-624-21	PIN, CONNECTOR 7P			
		< IC >			
IC001	8-759-339-63	IC NJM2118V-TE2			
IC002	8-759-490-54	IC BA3308FV-E2			
		< COIL >			
L001	1-414-754-11	INDUCTOR 10uH			
		< RESISTOR >			
R001	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R002	1-216-809-11	METAL CHIP	100	5%	1/16W
R003	1-216-833-11	METAL CHIP	10K	5%	1/16W
R004	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R005	1-216-817-11	METAL CHIP	470	5%	1/16W
R006	1-216-841-11	METAL CHIP	47K	5%	1/16W
R007	1-216-841-11	METAL CHIP	47K	5%	1/16W
R008	1-216-835-11	METAL CHIP	15K	5%	1/16W
R009	1-216-857-11	METAL CHIP	1M	5%	1/16W
R011	1-216-864-11	METAL CHIP	0	5%	1/16W
R013	1-216-817-11	METAL CHIP	470	5%	1/16W
R014	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R015	1-216-864-11	METAL CHIP	0	5%	1/16W
R017	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R020	1-216-847-11	METAL CHIP	150K	5%	1/16W
		< SWITCH >			
S001	1-692-247-11	SWITCH, TACTIL (2 CLICK)(SHUTTER)			

Note :
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Note :
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
		MISCELLANEOUS	
		**********	
2	1-959-175-11	HARNESS (RL-51)	
⚠5	1-418-071-11	FLASH UNIT (50080)	
7	1-418-072-11	BLOCK (50080), MF	
52	1-759-679-11	DRIVE, FLOPPY DISK (3.5 INCH)	
71	1-958-571-11	HARNESS (SP-151)	
106	1-758-217-11	FILTER BLOCK, OPTICAL	
110	8-848-730-01	DEVICE, LENS LSV-550B(SOC)	
IC431	A-7030-955-A	CCD BLOCK ASSY (CCD IMAGER)	
J901	1-694-297-31	TERMINAL BOARD, BATTERY	
LCD901	1-803-036-21	INDICATOR MODULE, LIQUID CRYST	
MIC901	1-542-312-11	MICROPHONE	
⚠ND901	1-517-787-11	TUBE, FLUORESCENT,COLD CATHODE	
SP901	1-529-174-11	SPEAKER (DIA. 20MM)	
		ACCESSORIES	
		**********	
⚠	1-569-007-11	ADAPTOR, CONVERSION 2P (JE)	
⚠	1-569-008-21	ADAPTOR, CONVERSION 2P (E)	
⚠	1-696-819-11	CORD, POWER (2m) (AUS)	
* ⚠	1-769-322-11	CORD, POWER 2P (2m) (JE)	
⚠	1-769-608-11	CORD, POWER (2m) (AEP,UK,E,HK)	
⚠	1-770-019-11	ADAPTOR, CONVERSION PLUG 3P (UK,HK)	
⚠	1-775-549-21	CORD, POWER (2m) (US,CND)	
⚠	1-782-476-11	CORD, POWER (2m) (CN)	
	3-864-060-11	MANUAL, INSTRUCTION (ENGLISH,FRENCH,CHINESE,SPANISH)	
	3-864-060-21	MANUAL, INSTRUCTION (ITALIAN,DUTCH,PORTUGUESE,RUSSIAN) (AEP,E,HK,CN)	
	3-864-060-31	MANUAL, INSTRUCTION (CHINESE,KOREAN,ARABIC) (E,HK,CN,JE)	
	3-864-060-41	MANUAL, INSTRUCTION (SWEDISH) (AEP)	
	3-864-932-11	MANUAL, INSTRUCTION (ENGLISH/SPANISH)	
	3-864-932-21	MANUAL, INSTRUCTION (GERMAN/FRENCH) (CND,AEP,JE)	
	3-864-932-31	MANUAL, INSTRUCTION (ITALIAN/DUTCH) (AEP)	
	3-864-932-41	MANUAL, INSTRUCTION (PORTUGUESE/RUSSIAN) (AEP,E,HK,CN)	
	3-864-932-51	MANUAL, INSTRUCTION (TRADITIONAL/SIMPLIFIED CHINESE) (E,HK,CN,JE)	
	3-864-932-61	MANUAL, INSTRUCTION (ARABIC/KOREAN) (E,HK,CN,JE)	
	3-864-932-71	MANUAL, INSTRUCTION (SWEDISH) (AEP)	
	3-987-015-01	BELT (S), SHOULDER	
	X-3949-054-1	CAP ASSY, LENS	
	A-7029-111-A	BC-V615 AC POWER ADAPTOR	
	A-7093-731-A	NP-F330 BATTERY PACK (US,CND)	
	A-7093-732-A	NP-F330 BATTERY PACK (EXCEPT US,CND)	

Be sure to read “Note on the CCD imager replacement” on page 4-7 when changing the CCD Imager.

Note : The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	**Note :** Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

〈FOR CAMERA COLOR REPRODUCTION ADJUSTMENT〉

: WEIGHT OFF MODE
: WEIGHT ON MODE

Take a copy of CAMERA COLOR REPRODUCTION FRAME and Parts referencesheets with a clear sheet for use.



MVC-FD81

〈PARTS REFERENCE SHEET〉

You can find the parts position of location of mount locations applying to FC-67 board of a set.

FC-67 MVC-FD81 SIDE A



SIDE B MVC-FD81 FC-67

9-974-116-11

Sony Corporation
Personal A&V Products Company

98I1670-1
Printed in Japan ©1998.9
Published by Quality Engineering Dept.
(Osaki East)